

MCR-MGT Management Module

Command Line Interface Guide

December 2017
Version A.12.22.2017
Part #5500311-16 (Rev B)

Copyright Statement

This document must not be reproduced in any way whatsoever, either printed or electronically, without the consent of:

Perle Systems Limited,
60 Renfrew Drive
Markham, ON
Canada
L3R 0E1

Perle reserves the right to make changes without further notice, to any products to improve reliability, function, or design.

Perle Systems Limited, 2010 - 2017.



Table of Contents

Preface	9
About This Book	9
Intended Audience.....	9
Typeface Conventions.....	9
Chapter 1 Introduction.....	10
CLI Conventions	10
Command Syntax	10
Command Shortcuts	10
Command Options	11
Chapter 2 MCR-MGT Module Specific Commands	12
MCR-MGT Server Commands.....	12
Set Server.....	12
Show Server.....	13
Set Service	13
Set Display Format.....	14
Show Display Format.....	14
SSH Server Commands.....	15
Set SSH-Server	15
Show SSH-Server	16
Hardware Commands	17
Set Console.....	17
Show Console.....	17
Set Ethernet	17

Show Hardware.....	18
Authentication Commands	19
Set authentication	19
Set authentication Kerberos.....	19
Set authentication LDAP/Active Directory	19
Set authentication NIS	21
Set Authentication RADIUS	21
Add RADIUS	22
Delete RADIUS	22
Set Authentication TACACS+.....	22
Set Authentication SecurID	23
Show Authentication.....	24
Email Commands	25
Set Email-Alert Server.....	25
Show Email-Alert Server.....	26
Dynamic DNS Commands	27
Set Dynamic-DNS	27
Set Dynamic-DNS SSL	27
Set Dynamic-DNS SSL Cipher-Suite.....	29
Show Dynamic-DNS	30
IPv6 Commands	31
Set IPv6.....	31
Show IPv6.....	31
Add Custom-IPv6 (Set Custom-IPv6).....	31
Delete Custom-IPv6.....	32
Chapter 3 Chassis/slot Commands	33
Chassis Commands.....	33
Set Chassis Temperature-Threshold.....	33
Set Chassis serial.....	33
Set Chassis management-module-slot	33
Set slot common parameters	34
Set slot, power schedule	34

Slot Control Commands	35
Slot reset	35
Slot reset to factory	35
Slot power	35
Slot virtual-cable-test	35
Slot loopback	35
Slot register read/write	35
Slot link-test	36
Slot sfp/xfp (read memory)	36
Slot Configuration Commands	37
Set slot... cm-100	37
Set slot... cm-100mm	38
Set slot... cm-1000	38
Set slot... cm-1000mm	40
Set slot... cm-110	41
Set slot... cm-1110	46
Set slot... cm-10g	51
Set slot... cm-10gt	53
Set slot... cm-4gpt	55
Set slot... ex	56
set slot... cm-10gr	60
set slot... cm-10grt	65
Show slot * command	69
Show slot # command	70
Show chassis alerts	70
Show chassis details	70
Chapter 4 User Commands	71
Commands for active sessions	71
Admin	71
Help	71
Logout	71
Menu	71
Ping	71

Screen.....	72
Set Termttype.....	72
Syslog Console.....	72
Show Termttype.....	72
Version	72
Configuring Users.....	72
Add User.....	72
Delete User.....	73
Set User	73
Show User	73
Chapter 5 Network Commands	74
SNMP Commands	74
Add Community.....	74
Set SNMP.....	74
Set SNMP V3-Security.....	75
Set snmp-trap common	75
Set snmp-trap entry.....	75
Set snmp-trap v3	76
Delete Community	77
Show SNMP.....	77
Hosts Commands	78
Add Host.....	78
Delete Host.....	78
Set Host.....	78
Show Hosts	78
Add Authorized Host.....	79
Delete Authorized Host.....	79
Set Authorized Host	79
Show Authorized Hosts	79
DNS Commands	80
Add DNS	80
Delete DNS	80

Show DNS	80
Gateway Commands.....	81
Add Gateway.....	81
Delete Gateway.....	81
Set Gateway	81
Show Gateways	82
Logging Commands	83
Set Syslog	83
Show Syslog	83
Set event-log.....	83
IPv6 Tunnels.....	84
Add IPv6tunnel	84
Set IPv6tunnel.....	84
Show IPv6tunnel.....	84
Delete IPv6tunnel.....	84
Chapter 6 Administration Commands	85
Administration Commands	85
Reboot	85
Reset Factory.....	85
Set Firmware auto-update	85
Show Firmware auto-update	85
Save	85
Set Bootup	85
Show text-config.....	86
Show Bootup	86
TFTP File Transfer Commands.....	87
Netload configuration and firmware	87
Netsave configuration.....	87
Keys and Certificates Commands.....	89
Netload keys	89
Netsave keys.....	89

Netload Media Converter Modules.....	90
Netload Serialt-buf.....	90
Netload sntp-keys.....	90
Chapter 7 Time Commands	91
Time Commands	91
Set Time.....	91
Set Timezone	91
Show Time.....	91
Show Timezone	91
SNTP Commands	92
Add SNTP.....	92
Delete SNTP	92
Set SNTP	92
Show SNTP	93
Show SNTP-Info.....	93
Time/Date Setting Commands	94
Set Date	94
Set Summertime	94
Set Summertime Fixed.....	94
Set Summertime Recurring	94
Show Date	95
Show Summertime	95
Chapter 8 Statistics Commands	96
Configuration Statistics	96
Show Interface.....	96
Run-Time Statistics	96
Delete Arp.....	96
Show Arp.....	96
Uptime	96



Preface

About This Book

This guide provides the information you need to:

- configure the MCR-MGT Management Module using the Command Line Interface (CLI)

Intended Audience

This guide is for administrators who will be configuring the MCR-MGT Management Module. Some prerequisite knowledge is needed to understand the concepts and examples in this guide:

- If you are using an external authentication application(s), working knowledge of the authentication application(s).
- Knowledge of TFTP the transfer protocols the MCR-MGT Management Module uses.

Typeface Conventions

Most text is presented in the typeface used in this paragraph. Other typefaces are used to help you identify certain types of information. The other typefaces are:

Typeface Example	Usage
At the C: prompt, type: <code>add host</code>	This typeface is used for code examples and system-generated output. It can represent a line you type in, or a piece of your code, or an example of output.
Set the value to TRUE .	The typeface used for TRUE is also used when referring to an actual value or identifier that you should use or that is used in a code example.
<code>subscribe <i>project</i> <i>subject</i></code> <code>run yourcode.exec</code>	The italicized portion of these examples shows the typeface used for variables that are placeholders for values you specify. This is found in regular text and in code examples as shown. Instead of entering <i>project</i> , you enter your own value, such as <i>stock_trader</i> , and for yourcode , enter the name of your program.
<i>MCR-MGT Management Module User's Guide</i>	This typeface indicates a book or document title.
See <i>About This Book on page 9</i> for more information.	This indicates a cross-reference to another chapter or section that you can click on to jump to that section.



Introduction

CLI Conventions

This section explains how to interpret the CLI syntax. Not all CLI commands are available on all product models.

Command Syntax

Each command is broken down into several categories:

- **Description**—Provides a brief explanation of how the command is used.
- **User Level**—Shows which user level(s) (Operator and/or Admin) can issue the command.
- **Syntax**—Shows the actual command line options. The options can be typed in any order on the command line. The syntax explanation will use the following command to break down the command syntax:

```
set service [telnetd on|off] [sshd on|off] [httpd on|off]
[httpsd on|off] [snmpd on|off] [setip on|off]
```

- Square brackets ([]) show the options that are available for the command. You can type a command with each option individually, or string options together in any order you want. For example,
set service sshd on telnetd off
- Angle brackets (<>) show that the text inside the brackets is a description for a variable value that you must fill in according to your requirements. In the **set server** command, you must determine the values for **domain**, **internet**, **name**, **password-limit**, and **subnet-bit-length**, if you wish to specify them and not use their defaults (default values provided in the **Options** description). The angle brackets can also contain a range that can be used.
- The pipe (|) shows an 'or' condition. For example, valid values for **telnetd** are either **on** or **off**.
- **Options**—Provides an explanation of each of the options for a command and the default value if there is one. Some commands do not have any options, so this category is absent.

Command Shortcuts

When you type a command, you can specify the shortest unique version of that command or you can press the **ESC** or **TAB** key to complete the command. For example, the following command:

```
set ethernet crossover auto
```

can be typed as:

```
set eth cro a
```

or, you can use the **ESC** key to complete the lines as you go along:

```
set eth<ESC>ernet cr<ESC>osserver a<ESC>uto
```

where the **ESC** key was pressed to complete the option as it was typed.

Command Options

When you are typing commands on the command line (while connected to the MCR-MGT Management Module), you can view the options by typing a question mark (?), **ESC**, or **TAB** key after any part of the command to see what options are available/valid. For example:

```
MCR-MGT-100903#set console ?
data-bits
flow
mode
monitor-dsr
parity
speed
stop-bits
MCR-MGT-100903#set console mode ?
disabled
enabled
MCR-MGT-100903#set console mode enabled ?
data-bits
flow
mode
monitor-dsr
parity
speed
stop-bits
Or press <ENTER> to confirm command
MCR-MGT-100903#set console mode enabled
MCR-MGT-100903#
```



MCR-MGT Module Specific Commands

MCR-MGT Server Commands

Set Server

Description	Sets high level parameters for the MCR-MGT Management Module.
User Level	Admin
Syntax	<pre>set server [auto-obtain-dns] [auto-obtain-gw] [dhcp-update-dns] [domain <text>] [name <text>] [incoming-pings enabled disabled] [internet dhcp/bootp on off <ipv4-address>] [netmask <ipv4-address>] [session-timeout <number in seconds>] tftp] [ssl-passphrase <text>]</pre>
auto-obtain-dns	When DHCP/BOOTP is enabled, the MCR-MGT Management Module will receive the DNS IP address from the DHCP/BOOTP server.
auto-obtain-gw	When DHCP/BOOTP is enabled, the MCR-MGT Management Module will receive the Default Gateway IP address from the DHCP/BOOTP server.
dhcp-update-dns	When this parameter is set, the MCR-MGT Management Module will provide the DHCP server with a fully qualified domain name (FQDN), so that the DHCP server can update the network's DNS server with the newly assigned IP address. Default: Disabled
domain	This field is combined with the System Name to construct the fully qualified domain name (FQDN). For example, if the domain is mycompany.com and the Server Name is set to accounting , the FQDN would be accounting.mycompany.com .
incoming-pings	The MCR-MGT management module will respond to incoming pings. Default: Enabled
name	The System Name is used for informational purposes by such tools as the MCR Web Manager and is also used in conjunction with the Domain field to construct a fully qualified domain name (FQDN). Default: MCR-MGT-xxxxxx (where xxxxxx is the last 6 digits of the Management Module's MAC address).
internet	This option accepts one of two parameters, ipv4 address or dhcp/bootp. ipv4 address - this parameter is followed by the IP address you wish to set for the Ethernet interface on the MCR-MGT Management Module. dhcp/bootp - this parameter is followed by an "on" or "off" directive. It enables or disables the use of DHCP as a method for obtaining the IP information for the Ethernet port of the MCR-MGT Management Module.
netmask	The IPv4 subnet mask you wish to assign to the MCR-MGT management module's Ethernet port. For example, 255.255.0.0

session- timeout	The session inactivity timer is only used when “Bypass login” is not enabled (i.e. login is required). If no activity is detected on the session for the amount of time configured here in seconds, the session will be terminated. The default timeout is 3600 seconds (60 minutes)
tftp	This option takes up to two parameters, retry and timeout. Retry is the number of times the Management Module will retry to transmit a TPFT packet to/from a host when no response is received. Enter a value between 0 and 5. The default is 5 . A value of 0 (zero) means no retry. Timeout, in seconds, that the Management Module will wait for a successful transmit or receipt of TFTP packets before retrying a TFTP transfer. Enter a value between 3 and 10. The default is 3 seconds.
ssl-passphrase	This is the SSL/TLS passphrase used to generate an encrypted RSA/DSA private key. This private key and passphrase are required for both HTTPS and SSL/TLS connections, unless an unencrypted private key was generated, then the SSL passphrase is not required. Make sure that you download the SSL private key and certificate if you are using the secure HTTP option (HTTPS) or SSL/TLS. If both RSA and DSA private keys are downloaded to the MCR-MGT Management Module, they need to be generated using the same SSL passphrase for both to work.

Show Server

Description	Shows the parameters set for the server.
User Level	Admin, Operator
Syntax	show server

Set Service

Description	Enables or disables the given service on the MCR-MGT Management Module. If disabled, the module does not listen for connections on that service.
User Level	Admin
Syntax	set service [telnetd] [sshd] [httpd] [httpsd] [snmpd] [setip] For each service above, you can enter "on" or "off" to enable or disable the service.

Set Display Format

Description	Configures the display preferences for a number of items.
User Level	Admin
Syntax	set display-format [date] [temperature] [time] [sfp-power]
date	The Date can be express in the following formats: <ul style="list-style-type: none"> ● MM/DD/YYYY ● DD/MM/YYYY ● YYYY-MM-DD Default: MM/DD/YYYY
temperature	Temperature can be expressed as Celsius or Fahrenheit.
time	Time can be express in the following formats: <ul style="list-style-type: none"> ● 12-Hour Clock ● 24-Hour Clock Default: 12-Hour Clock
sfp-power	Power can be expressed in mW(milliwatts) or dBm (decibel milliwatts) for SFP modules.

Show Display Format

Description	shows the display preferences.
User Level	Admin, Operator
Syntax	show display-format Shows the format for Date, Time, Temperature and SFP module.

SSH Server Commands

Set SSH-Server

See *Keys and Certificates* in the *MCR-MGT Management User's Guide* for information about the keys and certificates that need to be uploaded or downloaded with the MCR-MGT Management Modules SSH server.

Description	Configures the MCR-MGT Management Modules SSH server.
User Level	Admin
Syntax	<code>set ssh-server [authentication [RSA[on off] [DSA on off] [keyboard-interactive on off] [password on off] [compression on off] [verbose on off]] [ssh1 on off] [cipher 3des blowfish aes cast arcfour aes-ctr aes-gcm chachapoly1305]</code>
authentication	<p>Defines the authentication method to be used by the MCR-MGT Management Module's SSH server. The valid options are;</p> <p>RSA</p> <p>DSA</p> <p>Keyboard-interactive</p> <p>Password. - (only valid for SSH1).</p> <p>You can select one or more options. The authentication method is followed by "on" or "off" to enable or disable this authentication method.</p>
compression	<p>This parameter enables or disables compression. Typically compression is not required on fast networks (may actually slow things down). The valid options are;</p> <p>On - turn compression on.</p> <p>Off - turn compression off.</p>
verbose	<p>Displays debug messages on the terminal.</p> <p>On - turn on debug.</p> <p>Off - turn off debug.</p>
ssh1	<p>Allows the user's client to negotiate an SSH-1 connection, in addition to SSH-2.</p> <p>On - turn on ssh1.</p> <p>Off - turn off ssh1.</p>
cipher	<p>This parameter defines the ciphers which will be negotiated with the client. The following ciphers can be enabled;</p> <p>3des</p> <p>blowfish</p> <p>aes</p> <p>cast</p> <p>arcfour</p> <p>aes-ctr</p> <p>aes-gcm</p> <p>chacha20-poly1305</p> <p>You can select one or more options. The cipher is followed by "on" or "off" to have it included or not included in the negotiated list.</p>

Show SSH-Server

Description	Shows the SSH server settings.
User Level	Admin, Operator
Syntax	show ssh-server

Hardware Commands

Set Console

Description	Sets the operating parameters of the console port.
User Level	Admin
Syntax	<code>set console [flow soft hard both] [speed 9600 19200 38400 57600 115200] [data-bits 7 8] [mode enabled disabled] [monitor-dsr on off] [stop-bits 1 2] [parity even odd none]</code>
Flow	Defines whether the data flow control is handled by using software (Soft), hardware (Hard), software and hardware (Both) or no flow control at all (None).
Speed	Specifies the baud rate of the serial console port. Data Options: 9600, 19200, 38400, 57600 or 115200 Default: 9600
Data-bits	Specifies the number of bits in a transmitted character. Data Options: 7, 8 Default: 8
Mode	Enables/Disables the serial console port. Default: Enabled
Monitor-dsr	Specifies whether the EIA-232 signal DSR (Data Set Ready) should be monitored. on the serial console port. When the DSR signal is dropped (turn off terminal), the session is terminated. If login is required, will force user to login next time terminal is powered up. Default: Off
Stop-bits	Specifies the number of stop bits that follow a byte. Data Options: 1, 2 Default: 1
Parity	Specifies the type of parity being used for the data communication on the serial port. Data Options: Even, Odd, None Default: None

Show Console

Description	Displays the configured parameters of the console port.
User Level	Admin, Operator
Syntax	<code>show console</code>

Set Ethernet

Description	Sets the hardware configuration for the Ethernet port(s).
User Level	Admin
Syntax	<code>set ethernet [crossover] [speed-and-duplex]</code>

crossover	<p>This options sets the method by which the Ethernet's cable polarity will be set. The following options are available;</p> <ul style="list-style-type: none"> ● Auto— automatically detects the Ethernet's cable polarity ● MDI —the cable's polarity is straight-through ● MDI-X —the cable's polarity is crossovered <p>The default setting for this parameter is "Auto"</p>
speed-and-duplex	<p>Define the Ethernet connection.</p> <p>Data Options:</p> <ul style="list-style-type: none"> ● Auto—automatically detects the Ethernet interface speed and duplex ● 10 Mbps/Half Duplex ● 10 Mbps/Full Duplex ● 100 Mbps/Half Duplex ● 100 Mbps/Full Duplex ● 1000 Mbps/Half Duplex <p>Default: Auto</p>

Show Hardware

Description	Shows the hardware resources, Ethernet link status, date and time.
User Level	Admin, Operator
Syntax	show hardware

Authentication Commands

Set authentication

Description	Sets the authentication method for the MCR-MGT Management Module.
User Level	Admin
Syntax	<code>set authentication [type primary secondary radius kerberos ldap nis securid tacacs+ none] [bypass-login on off] [secondary-as-backup disabled enabled]</code>
type	<p>You can define up to two authentication methods which will be used to grant access to users accessing the MCR-MGT Management Module. The type parameter defines which method is used first as well as the type of authentication associated with that method.</p> <p>The first parameter for type is the designation of "primary" or "secondary". The "primary" authentication method is the one that the MCR-MGT Management Module attempts first. If a secondary method is also defined, it may or not be used depending on the setting of the "secondary-as-backup" parameter.</p> <p>The next parameter after the "primary" or "secondary" will be the authentication type. The following types can be specified.</p> <p>radius, kerberos, ldap, nis, securid, tacacs+ or none.</p>
bypass-login	<p>This defines whether users accessing the MCR-MGT Management Module will be required to login before gaining access the unit. The next parameter is as follows;</p> <p>on - users will be required to login.</p> <p>off - users will not be required to login.</p>
secondary-as-backup	<p>If this option is selected (enabled), the secondary authentication method will only be attempted if the MCR-MGT module can not reach the primary authentication host. (i.e. if the primary authentication host indicates that the user does not have access, the secondary authentication method will not be attempted). In other words, the secondary is only used as a backup to the primary in case the primary is not available.</p> <p>If this options is not selected (disabled), the secondary authentication will always be tried if the primary authentication is not successful (for any reason including an indication from the primary that the user is not authenticated).</p> <p>Default: Disabled (not selected).</p>

Set authentication Kerberos

Description	Configures Kerberos authentication settings.
User Level	Admin
Syntax	<code>set authentication kerberos [kdc-domain <text>] [port <number>] [realm <text>]</code>
kdc-domain	The name of a host running the KDC (Key Distribution Center) for the specified realm. The host name that you specify must either be defined in the MCR-MGT Management Module's Host Table before the last reboot or be resolved by DNS.
port	The port that the Kerberos server listens to for authentication requests. Default: 88
realm	The Kerberos realm is the Kerberos host domain name, in upper-case letters.

Set authentication LDAP/Active Directory

Description	Configures LDAP/Active Directory authentication settings.
User Level	Admin

Syntax	<code>set authentication ldap [base] [client append-base authenticate name password] [encrypt-password] [host] [port] [tls] [tls-port] [user-attribute other sAMAccountName uid]</code>
base	The domain component (dc) that is the starting point for the search for user authentication.
client	Enables/disables appending the base domain component (dc) to the client name field. Enables/disables whether the MCR-MGT Management Module will authenticate itself to the LDAP Server. The name to be used by the MCR-MGT Management Module to authenticate to the LDAP Server. The password to be used when authenticating to the LDAP Server
encrypt-password	When followed by the "MD5" parameter, the MCR-MGT Management Module will encrypt the user's and the MCR-MGT Management Module password strings using MD5 digest. If followed by "none", no encryption will be performed.
host	The name or IP address of the LDAP/Microsoft Active Directory host. If you use a host name, that host must either have been defined in the MCR-MGT Management Module's Host Table before the last reboot or be resolved by DNS. If you are using TLS , you must enter the same string you used to create the LDAP certificate that resides on your LDAP/Microsoft Active Directory server.
port	The port that the LDAP/Microsoft Active Directory host listens to for authentication requests. Default: 389
tls	Enables/disables the Transport Layer Security (TLS) with the LDAP/Microsoft Active Directory host. Default: Disabled.
tls-port	Specify the port number that LDAP/Microsoft Active Directory will use for TLS . Default: 636
user-attribute	This defines the name of the attribute used to communicate the user name to the server. Options: <ul style="list-style-type: none"> ● OpenLDAP(uid)—Chose this option if you are using an OpenLDAP server. The user attribute on this server is "uid". ● Microsoft Active Directory(sAMAccountName)—Chose this option if your LDAP server is a Microsoft Active Directory server. The user attribute on this server is "sAMAccountName". ● Other—If you are running something other than a OpenLDAP or Microsoft Active Directory server, you will have to find out from your system administrator what the user attribute is and enter it in this field. Default: OpenLDAP(uid)

Set authentication NIS

Description	Sets NIS authentication parameters.
User Level	Admin
Syntax	<code>set authentication nis [domain] [primary] [secondary]</code>
domain	The NIS domain name.
primary	The primary NIS host that is used for authentication. Default: None
secondary	The secondary NIS host that is used for authentication, should the primary NIS host fail to respond. Default: None

Set Authentication RADIUS

Description	Sets RADIUS parameters.
User Level	Admin
Syntax	<code>set authentication radius [accounting] acct-authenticator] [acct-port] [auth-port] attributes [nas-identifier nas-ip-address nas-ipv6-address] [retry] [timeout]</code>
accounting	Enables/disables RADIUS accounting. Default: Disabled
acct-authenticator	Enables/disables whether or not the MCR-MGT Management Module validates the RADIUS accounting response. Default: Enabled
acct-port	The port that the RADIUS host listens to for accounting requests. Default: 1813
auth-port	The port that the RADIUS host listens to for authentication requests. Default: 1812
attributes	
nas-identifier	This is the string that identifies the Network Address Server (NAS) that is originating the Access-Request to authenticate a user. Field Format: Maximum 31 characters, including spaces
nas-ip-address	When enabled, the MCR-MGT Management Module will send the MCR-MGT Management Module's Ethernet IPv4 address to the RADIUS server. Default: Enabled
nas-ipv6-address	When enabled, the MCR-MGT Management Module will send the specified IPv6 address to the RADIUS server. Default: Disabled
retry	The number of times the MCR-MGT Management Module tries to connect to the RADIUS server before erroring out. Range: 0-255 Default: 5

timeout	The time, in seconds, that the MCR-MGT Management Module waits to receive a reply after sending out a request to a RADIUS accounting or authentication host. If no reply is received before the timeout period expires, the MCR-MGT Management Module will retry the same host up to and including the number of retry attempts. Range: 1-255 Default: 3 seconds
----------------	--

Add RADIUS

Description	Adds an accounting or authentication RADIUS host.
User Level	Admin
Syntax	add radius [accounting-host] [auth-host]
accounting-host	The first time this command is entered, this is the name of the primary RADIUS accounting host. The second time this command is entered, this is the name of the secondary RADIUS accounting host.
auth-host	The first time this command is entered, this is the name of the primary RADIUS authentication host. The second time this command is entered, this is the name of the secondary RADIUS authentication host, should the first RADIUS host fail to respond.
secret	For both of the above, you can specify the "secret" associated with each host. The secret is the password which is shared between the MCR-MGT Management Module and the RADIUS host. After typing the command secret and pressing Enter , you will be prompted to enter the secret and then re-enter the secret.

Delete RADIUS

Description	Deletes an accounting or authentication RADIUS host.
User Level	Admin
Syntax	delete radius [accounting] [authentication]
accounting	Deletes the specified accounting host from the RADIUS authentication settings.
authentication	Deletes the specified authentication host from the RADIUS authentication settings.

Set Authentication TACACS+

Description	Configures TACACS+ authentication settings.
User Level	Admin
Syntax	set authentication tacacs+ [port] [primary] [secondary] [secret] [alternate-service-names] [authorization] [accounting] [acct-port] [acct-primary] [acct-secondary] [acct-secret]
port	The port number that TACACS+ listens to for authentication requests. Default: 49
primary	The primary TACACS+ host that is used for authentication. Default: None
secondary	The secondary TACACS+ host that is used for authentication, should the primary TACACS+ host fail to respond. Default: None

secret	The TACACS+ shared secret is used to encrypt/decrypt TACACS+ packets in communications between two devices. The shared secret may be any alphanumeric string up to 30 characters. Each shared secret must be configured on both client and server sides.
secret	The TACACS+ shared secret is used to encrypt/decrypt TACACS+ packets in communications between two devices. The shared secret may be any alphanumeric string up to 30 characters. Each shared secret must be configured on both client and server sides.
alternate-service-names	The TACACS+ service name for Telnet or SSH is normally “raccess”. The service name for MCR Web Manager is “EXEC”. In some cases, these service names conflicted with services used by Cisco devices. If this is the case, checking this field will cause the service name for Telnet or SSH to be “perlecli” and the service name for MCR Web Manager to be “perleweb”.
accounting	Enables/disables TACACS+ accounting. Default: Disabled
acct-port	The port number that TACACS+ listens to for accounting requests. Default: 49
acct-primary	The primary TACACS+ host that is used for accounting. Default: None
acct-secondary	The secondary TACACS+ host that is used for accounting, should the primary accounting TACACS+ host fail to respond. Default: None
acct-secret	The TACACS+ shared secret is used to encrypt/decrypt TACACS+ packets in communications between two devices. The shared secret may be any alphanumeric string. Each shared secret must be configured on both client and server sides.

Set Authentication SecurID

Description	Configures SecurID authentication settings.
User Level	Admin
Syntax	<pre>set authentication securid [primary host][port] [encryption] [legacy] set authentication securid [replica host][port] [encryption] [legacy] set authentication securid reset secret</pre>
primary host	The first SecurID server that is tried for user authentication. Default: None
replica host	If the first SecurID server does not respond to an authentication request, this is the next SecurID server that is tried for user authentication. Default: None
port	The port number that SecurID listens to for authentication requests. Default: 5500

encryption	The type of encryption that will be used for SecurID server communication. Data Options: DES, SDI Default: SDI
legacy	If you are running SecurID 3.x or 4.x, you need to run in Legacy Mode . If you are running SecurID 5.x or above, do not select Legacy Mode . Default: Disabled
reset secret	Resets the SecurID secret (password) in the MCR-MGT Management Module.

Show Authentication

Description	Shows the authentication settings. If you type just the show authentication command, the configured primary and secondary authentication methods are displayed.
User Level	Admin, Operator
Syntax	show authentication radius ldap tacacs+ nis kerberos securid
Option	radius ldap tacacs+ nis kerberos securid Displays the authentication settings for the specified authentication method.

Email Commands

Set Email-Alert Server

Description	Configures email alert settings for the server.
User Level	Admin
Syntax	<code>set email-alert server [from] [domain] [encryption] [level emergency alert critical error warning notice info debug] [mode] [to] [reply-to] [smtp-host] [password] [tcp-port] [username] [verify-peer] [subject]</code>
from	This will be the contents of the from field in the generated email. This field can contain an email address that might identify the Management Module name or some other value.
Domain	This field is only used if SPA authentication is performed with the email server. It may or may not be required. If the email server does not expect this field, it can be left blank.
Encryption	Choose the type of encryption desired. Valid options are; None - All information is sent in the clear. <ul style="list-style-type: none"> ● TLS - Select this if your email server requires TLSAll data from previous connections on that serial port has drained ● SSL - Select this if your email server requires SSL
level	Choose the alert level that will trigger an email notification to be sent out. Data Options: <ul style="list-style-type: none"> ● System-level Fault ● Module Level Fault ● Persistent Error ● One-time error ● Significant Event ● Normal Operation. The level selected is the minimum trigger level with the "Normal Operation" being the least severe and "System-level Fault" being the most severe. The level selected will include alerts of that level and all more severe levels above it. Default: System-level Fault
mode	Enables/disables Email Alerts. Default: Disabled
to	An email address or list of email addresses that will receive the email notification.
reply-to	The email address to whom all replies to the email notification should go.
smtp-host	The SMTP host (email server) that will process the email notification request. This can be either a host name defined in the MCR-MGT Management Module host table or the SMTP host IP address.
password	Enter the password associated with the user configured in "Username". Maximum size of password is 64 characters.
tcp-port	This is the TCP port used to communicate with the email server. Default: 25 for non-SSL, 465 if SSL/TLS is used

username	If your mail server requires you to authenticate with it before it will accept email messages, use this field to configure the authorized user name. Maximum size of user name is 64 characters.
verify-peer	<p>When checked this will enable the validation of the certificate presented by the email server. To validate the certificate, you will need to download the appropriate CA list into the Management Module. If the certificate is not found to be valid, the communication with the email server will be terminated. No authentication will take place and the email message will not be forwarded to the email server. If this option is not checked, the certificate validation will still be attempted but if it fails, a syslog message will be generated but the authentication and forwarding of the email will still take place.</p> <p>Default: Enabled if SSL or TLS encryption is selected. Disabled if no encryption is selected.</p>
subject	<p>A text string, which can contain spaces, that will display in the Subject field of the email notification.</p> <p>If the text string contains spaces, enclose the string in quotes.</p>

Show Email-Alert Server

Description	Shows how the server email alert is configured.
User Level	Admin, Operator
Syntax	<code>show email-alert server</code>

Dynamic DNS Commands

Set Dynamic-DNS

Description	Configures the dynamic DNS parameters.
User Level	Admin
Syntax	set dynamic-dns [on off] [connection-method] [hostname] [username] [password] [system-type] [wildcard]
on off	Enables/disables the dynamic DNS feature. When Dynamic DNS is enabled, the MCR-MGT Management Module will automatically update its IP address with DynDNS.org if it changes. Default: Disabled
hostname	Specify the registered hostname with DynDNS.org that will be updated with the MCR-MGT Management Module's IP address should it change. Put in the full name; for example, mymediaconverter.dyndns.org.
username	Specify the user name used to access the account set up on the DynDNS.org server.
password	Specify the password used to access the account set up on the DynDNS.org server.
system-type	Specify how your account IP address schema was set up with DynDNS.org. Refer to www.DynDNS.org for information about this parameter. Data Options: Dynamic, Static, Custom Default: Dynamic
wildcard	Specifies whether to add an alias such as *to your Registered Host Name .yourcompanySCS.dyndns.org pointing to the same IP address as entered for yourcompanySCS.dyndns.org . Data Options: Enable, Disable, Nochange Default: Enable

Set Dynamic-DNS SSL

Description	Sets the SSL/TLS parameters for the connection between the MCR-MGT Management Module and the DNS server.
User Level	Admin
Syntax	set dynamic-dns ssl [verify-peer][validation-criteria] [cipher-suite]
verify-peer	Enable this option when you want the Validation Criteria to match the Peer Certificate for authentication to pass. If you enable this option, you need to download an SSL/TLS certificate authority (CA) list file to the MCR-MGT Management Module.

validation-criteria Any values that are entered in the validation criteria must match the peer certificate for an SSL connection; any fields left blank will not be validated against the peer certificate. The following validation criteria can be set;

country - A two character country code; for example, US. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

state-province -Up to a 128 character entry for the state/province; for example, IL. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

locality - Up to a 128 character entry for the location; for example, a city. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

organization - Up to a 64 character entry for the organisation; for example, Accounting. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

organization-unit - Up to a 64 character entry for the unit in the organisation; for example, Payroll. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

common-name - Up to a 64 character entry for common name; for example, the host name or fully qualified domain name. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

email - Up to a 64 character entry for an email address; for example, acct@anycompany.com. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

Set Dynamic-DNS SSL Cipher-Suite

Description	Sets the SSL/TLS cipher suite parameters for the connection between the MCR-MGT Management Module and the DNS server.
User Level	Admin
Syntax	<pre>set dynamic-dns ssl cipher-suite [option1 option2 option3 option4 option5] [encryption] [min-key-size] [max-key-size] [key-exchange] [hmac]</pre>
option1-option5	Sets the priority of the cipher suite, with option1 being highest priority and option5 lowest priority.
encryption	<p>Select the type of encryption that will be used for the SSL connection:</p> <ul style="list-style-type: none"> ● any—Will use the first encryption format that can be negotiated. ● aes ● 3des ● des ● arctwo ● arcfour ● aes-gcm <p>The default value is any.</p>
min-key-size	<p>The minimum key size value that will be used for the specified encryption type. Valid options are;</p> <p>40, 56, 64, 128, 168 or 256</p> <p>The default is 40.</p>
max-key-size	<p>The maximum key size value that will be used for the specified encryption type. The Valid options are;</p> <p>40, 56, 64, 128, 168 or 256</p> <p>The default is 256.</p>
key-exchange	<p>The type of key to exchange for the encryption format:</p> <ul style="list-style-type: none"> ● Any—Any key exchange that is valid is used (this does not, however, include ADH keys). ● RSA—This is an RSA key exchange using an RSA key and certificate. ● EDH-RSA—This is an EDH key exchange using an RSA key and certificate. ● EDH-DSS—This is an EDH key exchange using a DSA key and certificate. ● ADH—This is an anonymous key exchange which does not require a private key or certificate. Choose this key if you do not want to authenticate the peer device, but you want the data encrypted on the SSL/TLS connection. ● ECDH-ECDSA—This is an ECDH key exchange using a ECDSA key and certificate. <p>The default is Any.</p>
hmac	<p>Select the key-hashing for message authentication method for your encryption type:</p> <ul style="list-style-type: none"> ● Any ● MD5 ● SHA1 ● SHA256 ● SHA384 <p>The default is Any.</p>

Show Dynamic-DNS

Description	Shows the dynamic DNS settings.
User Level	Admin, Operator
Syntax	<code>show dynamic-dns</code>

IPv6 Commands

Set IPv6

Description	Configures the basic IPv6 settings.
User Level	Admin
Syntax	set ipv6 [dhcpv6-settings] [enable-ipv6-addressing] [auto-obtain-dns-ipv6]
dhcpv6-settings	Determines the types of information that the MCR-MGT Management Module will accept from the DHCPv6 server, IPv6 address(es) and/or network prefix(es). ipv6-address - When enabled, the MCR-MGT Management Module will accept IPv6 address(es) from the DHCPv6 server. This is <code>off</code> by default. network-prefix - When enabled, the MCR-MGT Management Module will accept the network prefix from the DHCPv6 server. This is <code>off</code> by default.
enable-ipv6-addressing	When enabled, you can configure the MCR-MGT Management Module to obtain the IPv6 address(es) using IPv6 Autoconfiguration or a DHCPv6 server. Default: Enabled
auto-obtain-dns-ipv6	Enable or disable whether the MCR-MGT Management Module will obtain the DNS IPv6 address from the DHCPv6 server.

Show IPv6

Description	Shows the IPv6 settings.
User Level	Admin, Operator
Syntax	show ipv6

Add Custom-IPv6 (Set Custom-IPv6)

Description	
User Level	Admin
Syntax	add custom-ipv6 method [auto] [network-prefix] [prefix-bits] add custom-ipv6 method [manual] [ipv6-address] [prefix-bits]
auto	When this option is specified, the MCR-MGT Management Module will derive an IPv6 address from the entered network prefix and the MCR-MGT Management Module's MAC address. This is the default option.
network-prefix	Specify the IPv6 network prefix. The MCR-MGT Management Module will derive the complete IPv6 address from the entered network prefix and the MCR-MGT Management Module's MAC address.
prefix-bits (auto)	Specify the network prefix bits for the IPv6 address. Range: 0-64 Default: 64
manual	Specify this option when you want to enter a specific IPv6 address.
ipv6-address	Specify the complete IPv6 address. Field Format: IPv6 address
prefix-bits (manual)	Specify the network prefix bits for the IPv6 address. Range: 0-128 Default: 64

Delete Custom-IPv6

Description	Deletes the specified custom IPv6 address. To see a list of configured IPv6 addresses, type the command <code>delete custom-ipv6 ?</code> .
User Level	Admin
Syntax	<code>delete custom-ipv6 <config_ipv6_address></code>



Chassis/slot Commands

Chassis Commands

Depending on the module type some commands may or may not be available to you.

Set Chassis Temperature-Threshold

Description	Sets the temperature threshold for the MCR1900 chassis.
User Level	Admin
Syntax	<code>set chassis temperature-threshold <scale> <temperature></code>
scale	Specify whether the temperature will be specified in Celsius or Fahrenheit.
temperature	When the specified temperature is exceeded, alerts will be issued. Celsius 0-70 degrees Fahrenheit 32-158 degrees

Set Chassis serial

Description	Sets the serial number for a SMI Media Converter.
User Level	Admin
Syntax	<code>set chassis serial <text></code>
text	Sets the serial number for the SMI Media Converter. 16 characters

Set Chassis management-module-slot

Description	Sets the management module's slot number for the SMI Media Converter.
User Level	Admin
Syntax	<code>set chassis management-module-slot <1-2></code>
1-2	Specify whether the management module will be in slot 1 or slot 2.

Set slot common parameters

Description	Sets generic parameters for a slot within the chassis. These apply regardless of the type of module which is inserted into the slot.
User Level	Admin
Syntax	set slot <slot #> [auto-backup] [default-power]
slot #	Specify the slot number. Valid options are 1-19.
auto-backup	This enables or disables the auto backup or restore of the configuration for the card which is inserted into this slot. Valid options are 1-19.
default-power	This defines whether this slot will be powered up or not when the chassis is reset or powered up.

Set slot, power schedule

Description	Configure a scheduled power on/off for a specific slot.
User Level	Admin
Syntax	set slot <slot #> power-schedule entry [day] [on off] <hh:mm> [clear] set slot <slot #> power-schedule mode <enabled disabled>
entry	This command defines a new scheduled on or off time or clears an existing schedule.
day	This is the day of week on which to power the slot on or off.
on off	Defines if this is a power on or power off entry. Values: on or off
<hh:mm> clear	The time to power slot on or off. If "clear" is entered, it deletes an existing scheduled power on/off.
mode	This command defines is used to enable/disable the power schedule.

Slot Control Commands

Slot reset

Description	This command will reset the specified slot or the whole chassis. Specifying a * will reset the whole chassis.
User Level	Admin
Syntax	<code>slot <slot #> [reset][</code>
slot #	Specify a slot number <1-19>.
reset	<code>resets the module in that slot</code>

Slot reset to factory

Description	This command will reset the configuration of the specified slot to factory default. Specifying a * will reset the whole chassis to factory default.
User Level	Admin
Syntax	<code>slot <slot #> [reset factory]</code>
slot#	Specify a slot number <1-19>
factory	<code>resets the module to factory defaults</code>

Slot power

Description	This command will power a slot on or off.
User Level	Admin
Syntax	<code>slot <slot #> [power on off]</code>
slot#	1-19
power	<code>on off</code>

Slot virtual-cable-test

Description	This command will initiate a virtual cable test on the copper port of the specified slot.
User Level	Admin
Syntax	<code>slot <slot #> [virtual-cable-test]</code>
slot#	1-19

Slot loopback

Description	This command will initiate a fiber loopback on the fiber port of the specified slot.
User Level	Admin
Syntax	<code>slot <slot #> [loopback] [fiber-1 fiber-2 off] [1 2 off]</code>
slot#	1-19
loopback#	<code>fiber-1, fiber-2, 1, 2, on,off</code>

Slot register read/write

Description	This command will enable the user to read or write any registers on the Media Converter Module. This should only be used when instructed to do so by a Perle Support Representative.
User Level	Admin
Syntax	<code>slot <slot #> phy read write address <hex address> register <hex value> [device <hex value>[page <hex value>] [device assign clear-bits set-bits] <hex value></code>

Slot link-test

User Level	Admin
Syntax	<pre>slot <slot #> link-test [1 2 off] [send-snmp-trap-on-error enabled disabled] [packet-size <256-8960>] [modes random sequential alternating] [alternating random sequential] Default: 1500 bytes for 1 Gig modules Default: send-trap-on-error - Disabled</pre>
Description	<p>This command enables a port (on modules which support this feature) to perform link tests. These tests may be useful in identifying link issues.</p> <p>CM-10G modules</p> <p>The Link-Test on this module allows to generate patterns to be sent to the remote media converter. These tests can include packet sizes and data type to run.</p> <p>CM-10GT modules</p> <p>The Link Test ion this module involves sending a pattern to the remote peer, having him validate the pattern and send back a response indicating whether he received the pattern correctly or not. Based on the response from the peer, the local module is able to obtain one of three statuses for that transaction (which is repeated every second). See below for details.</p> <p><u>Link-Test Responses for CM-10GT</u></p> <p><u>Received</u></p> <ul style="list-style-type: none"> ● Good - The local module received a “good” response from the peer. ● Bad - The response received from the peer was received in error or not received at all <p><u>Transmitted:</u></p> <ul style="list-style-type: none"> ● Good - The remote peer indicated that the data sent by the local module was received correctly. ● Bad - The remote peer indicated that the data sent by the local module was received in error ● Unknown - The local module was unable to decode the message sent by the remote peer (this is a “bad” receive status). Since the local module is unable to decode what the peer sent back, it is unable to determine if the data it transmitted to the peer was received correctly. <p>Note: 1 gigabit modules do not support the link test when inserted in a 10GT module.</p>

Slot sfp/xfp (read memory)

Description	<p>This feature should only be used if guided by a Perle Technical Support Representative. Use of this feature without guidance from a Perle Technical Support Representative could make your Media Converter Module inoperable.</p>
User Level	Admin
Syntax	<pre>For SFP modules without DMI support slot <slot #> sfp [1 2] read a0 [start <start addr 0-ff>] [end <end addr 0-ff>] For SFP modules with DMI support slot <slot #> sfp [1 2] read [a0 a2][<page 0-ff>] [start <start addr 0-ff>] [end addr 0-ff>] For XFP modules with DMI support slot <slot #> xfp [1 2] read [<page 0-ff>] [start <start addr 0-ff>] [end addr 0-ff>]</pre>

Slot Configuration Commands

Set slot... cm-100

Description	Configure a cm-100 media converter module.
User Level	Admin
Syntax	<pre>set slot <slot #> cm-100 module [name <text>] [far-end-fault enabled disabled] [link-mode standard passthrough] set slot <slot #> cm-100 copper [port enabled disabled] [name <text>] [crossover auto mdi mdi-x] [auto-negotiation enabled disabled] [pause enabled disabled] set slot <slot #> cm-100 fiber [port enabled disabled] [name <text>]</pre>
module	This command defines parameters which apply to the whole media converter module.
name	The name to be associated with this module. Values: 0-63 characters
far-end-fault	When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will transmit a FEF signal to the remote Media Converter Module. This, in effect, notifies the fiber link partner that an error condition exists on the fiber connection. Note: This feature only takes effect if Auto Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Far End Fault.
link-mode	Standard: In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection. Smart Link Pass-Through: In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter. Default: Passthrough
copper	This command defines parameters which apply to the copper port of the media converter module.
port	Enable or disable this port.
name	The name to be associated with this port. 1-8 characters
auto-negotiation	When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection.
crossover	<ul style="list-style-type: none"> ● Auto-Detect— automatically detects the Ethernet's cable polarity ● MDI —the cable's polarity is straight-through ● MDI-X —the cable's polarity is crossovered Default: Auto
pause	When enabled, the Media Converter Module will advertise its Pause capabilities.

fiber	This command defines parameters which apply to the fiber port of the media converter module.
port name	Enable or disable this port. The name to be associated with this port. 1-8 characters

Set slot... cm-100mm

Description	Configure a cm-100mm media converter module.
User Level	Admin
Syntax	<pre>set slot <slot #> cm-100mm module [name <text>] [link-mode standard passthrough] [far-end-fault disabled enabled] set slot <slot #> cm-100mm fiber[1 2] [name <text>] [port enabled disabled]</pre>
module name	This command defines parameters which apply to the whole media converter module. The name to be associated with this module. 0-63 characters
link-mode	Smart Link Pass-Through: In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter. Standard: In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection. Default: Smart Link Pass-Through
far-end-fault	When enabled, if the media converter module detects a loss of signal on the fiber receiver, it will immediately send an FEF on the transmitter of its fiber link to the remote end module. This, in effect, notifies the fiber link partner that an error condition exists on the fiber link. connection. Note: This feature only takes effect if Auto Negotiation has been turned off. When disabled, the media converter module will not monitor for or generate Far End Fault. Default: On
name	The name to be associated with this port. 1-8 characters
fiber	This command defines parameters which apply to the fiber port of the media converter module.
port name	Enable or disable this port. The name to be associated with this port.

Set slot... cm-1000

Description	Configure a cm-1000 media converter module.
User Level	Admin

Syntax	<pre> set slot <slot #> cm-1000 module {auto-negotiation enabled disabled} [name <text>] [fiber-fault-alert enabled disabled]] [jumbo-packets enabled disabled] [link-mode standard smart-link-passthrough] set slot <slot #> cm-1000 copper [port] [name <text>] [duplex half auto] [low-power-mode enabled disabled] [pause disabled symmetrical asymmetrical-tx asymmetrical-rx] set slot <slot #> cm-1000 fiber [port] [name] [auto-negotiation] </pre>
module	This command defines parameters which apply to the whole media converter module.
auto-negotiation	<p>Enabled: The Media Converter Module will negotiate Ethernet parameters on the copper connection. This will ensure that the most optimal connection parameters will be in effect.</p> <p>Disabled: The Media Converter Module will negotiate the Ethernet parameter's with the copper link partner. The parameters used will be determined by the Duplex and Pause settings.</p>
name	<p>The name to be associated with this module.</p> <p>0-63 characters</p>
fiber-fault-alert	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p>Note: This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
jumbo-packets	<p>Enable Jumbo Packet support.</p> <p>Default: Enabled</p>
link-mode	<p>Standard: In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection.</p> <p>Smart Link Pass-Through: In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter.</p> <p>Default: Passthrough</p>
copper	This command defines parameters which apply to the copper port of the media converter module.
port	Enable or disable this port.
name	<p>The name to be associated with this port.</p> <p>1-8 characters</p>
duplex	<p>The following selections are available:</p> <p>Duplex: Auto, Half</p> <p>Default: Auto</p>
low-power-mode	If enabled, the Gigabit copper transceiver is set into low power mode which reduces the strength of the copper signal.

pause	<p>When enabled, the Media Converter Module will advertise the following Pause capabilities:</p> <ul style="list-style-type: none"> • Disabled • Symmetrical • Asymmetrical TX • Asymmetrical RX <p>Note: Pause feature will only work if Auto Negotiation is set to OFF on the fiber port and Duplex is set to Full.</p>
fiber	This command defines parameters which apply to the fiber port of the media converter module.
port	Enable or disable this port.
name	<p>The name to be associated with this port.</p> <p>1-8 characters</p>

Set slot... cm-1000mm

Description	Configure a cm-1000mm media converter module.
User Level	Admin
Syntax	<pre>set slot <slot #> cm-1000mm module [auto-negotiation enabled disabled] [name <text>] [fiber-fault-alert enabled disabled]] [jumbo-packets enabled disabled] [link-mode standard smart-link-passthrough] set slot <slot #> cm-1000mm fiber [port enabled disabled] [name <text>]</pre>
module	This command defines parameters which apply to the whole media converter module.
auto-negotiation	<p>Enabled: The Media Converter Module will negotiate Ethernet parameters on the fiber connection. This will ensure that the most optimal connection parameters will be in effect.</p> <p>Disabled: The Media Converter Module will negotiate the Ethernet parameter's with the copper link partner. The parameters used will be determined by the Duplex and Pause settings.</p>
name	<p>The name to be associated with this module.</p> <p>0-63 characters</p>
fiber-fault-alert	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p>Note: This feature only takes effect if Fiber Negotiation has been turned off.</p> <p>When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
jumbo-packets	<p>Enable Jumbo Packet support.</p> <p>Default: Enabled</p>

link-mode	<p>Smart Link Pass-Through: In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.</p> <p>Standard: In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.</p> <p>Default: Smart Link Pass-Through</p>
fiber	This command defines parameters which apply to the fiber port of the media converter module.
port	Enable or disable this port.
name	The name to be associated with this port. 1-8 characters

Set slot... cm-110

Description	Configure a cm-110 media converter module.
User Level	Admin
Syntax	<pre>set slot <slot #> cm-110 module [name <text>] [far-end-fault enabled disabled] [link-mode standard passthrough] [max-packet-size 1522 2048] [map-priority-to-egress-queue <0-7> <0-3>] [unidirectional-ethernet disabled copper-to-fiber fiber-to-copper] set slot <slot #> cm-110 copper [port enabled disabled] [name <text>] [crossover auto mdi mdi-x] [auto-negotiation enabled disabled] [pause enabled disabled] [10baset-distance normal extended] [8021p-priority enabled disabled] [ip-tos-priority enabled disabled] [priority-precedence 8021p ip-tos] [congestion-policy strict-queueing weighted-queueing] [remap- priority <0-7> <0-7>] [ingress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [default-priority <0-7>] [default-vlan-id <0-4095>] [discard-tagged-frames enabled disabled] [discard-untagged-frames enabled disabled] [vlan-tagging-action none untag tag double-tag] [filter-unknown-multicast enabled disabled] [filter-unknown-unicast enabled disabled]</pre>

```

set slot <slot #> cm-110 fiber [port enabled|disabled] [name
<text>] [duplex full|half] [8021p-priority enabled|disabled]
[tos-priority enabled|disabled] [priority-precedence
8021p|ip-tos] [congestion-policy
strict-queueing|weighted-queueing] [remap- priority <0-7> <0-7>]
[ingress-rate-limit none|64kbps|128kbps
|192kbps|256kbps|320kbps|384kbps|512kbps|768kbps|1mbps|2mbps
|3mbps|4mbps|5mbps|6mbps|7mbps|8mbps|9mbps|10mbps|20mbps|30mbps
|40mbps|50mbps|60mbps|70mbps|80mbps|90mbps] [egress-rate-limit
none|64kbps|128kbps|192kbps|256kbps|320kbps|384kbps|512kbps|768k
bps|1mbps|2mbps|3mbps|4mbps|5mbps|6mbps|7mbps|8mbps|9mbps|10mbps
|20mbps|30mbps|40mbps|50mbps|60mbps|70mbps|80mbps|90mbps]
[default-priority <0-7>] [default-vlan-id <0-4095>]
[discard-tagged-frames enabled|disabled] [discard-untagged-frames
enabled|disabled] [vlan-tagging-action
none|untag|tag|double-tag] [filter-unknown-multicast
enabled|disabled] [filter-unknown-unicast enabled|disabled]

```

module	This command defines parameters which apply to the whole media converter module.
name	The name to be associated with this module.
far-end-fault	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will transmit a FEF signal to the remote Media Converter Module. This, in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p>Note: This feature only takes effect if Auto Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Far End Fault.</p>
link-mode	<p>Standard: In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection.</p> <p>Smart Link Pass-Through: In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter.</p> <p>Default: Passthrough</p>
max-packet-size	<p>Select the maximum packet size.</p> <p>Options: 1522 bytes or 2048 bytes</p> <p>Default: 2048</p>
unidirectional-ethernet	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p>Values:</p> <ul style="list-style-type: none"> ● Disabled ● Copper to Fiber ● Fiber to Copper <p>Default: Disabled</p>
copper	This command defines parameters which apply to the copper port of the media converter module.
port	Enable or disable this port.

name	The name to be associated with this port. 1-8 characters
auto-negotiation	When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection.
crossover	<ul style="list-style-type: none"> ● Auto-Detect— automatically detects the Ethernet’s cable polarity ● MDI —the cable’s polarity is straight-through ● MDI-X —the cable’s polarity is crossovered Default: Auto
pause	When enabled, the Media Converter Module will advertise its Pause capabilities.
10baset-distance	Normal: the Media Converter copper link is in normal operating mode. Extended: the Media Converter will boost the signal strength on its copper link.
802.1p- priority	When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue. Default: Enabled
ip-tos- priority	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. Default: Enabled
priority- precedence	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. Default: 802.1p
congestion policy	Select a method to be used when determining the order by which frames are sent from the four egress queues. Setting the congestion policy on either the fiber or copper port will change the policy on both ports. Strict Priority Queuing - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues. Weighted Fair Queuing - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of (8, 4, 2, 1) . The ratio for 8 highest priority sent frames will be as follows: 8 highest priority frames from queue 3 4 frames from queue 2 2 frames from queue 1 1 frame from queue 0 Default: Strict Priority Queuing
remap-priority	Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to. Original Priority -----> New Priority Values: 0-7
ingress-rate	Restricts ingress frames on the copper port. Default: None Data Options: 64 kbps to 90 Mbps
egress-rate	Restricts egress frames on the copper port. Default: None Data Options: 64 kbps to 90 Mbps

discard-tagged frames	When enabled, discards all VLAN tagged frames. Default: Off
discard-untagged frames	When enabled, discards all VLAN untagged frames. Default: Off
default-vlan-id	Specify a default VLAN ID to insert when tagging frames. Default: 1 Data Options: 0-4095
default-priority	Specify a default VLAN priority to insert when tagging frames. Default: 0 Data Options: 0-7
vlan-tagging actions	Define the VLAN tagging action to take on a egress frame. <ul style="list-style-type: none"> ● Normal -Take no action. ● Untag - Remove any existing tag. ● Tag <ul style="list-style-type: none"> Insert tag with configured VLAN ID and VLAN priority if original frame is untagged. Replace tag with configured VLAN ID and VLAN priority if original frame is tagged. ● Double tag - Append a tag with configured VLAN ID and VLAN priority. Default: Normal
fiber	This command defines parameters which apply to the fiber port of the media converter module.
port	Enable or disable this port.
name	The name to be associated with this port. 1-8 characters
duplex	The following selections are available: Duplex: Full, Half Default: Full
8021p- priority	When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue. Default: Enabled
ip-tos	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. Default: Enabled
priority-precedence	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. Default: 802.1p

congestion-policy	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues. Setting the congestion policy on either the fiber or copper port will change the policy on both ports.</p> <p>Strict Priority Queuing - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p>Weighted Fair Queuing - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of (8, 4, 2, 1).</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <ul style="list-style-type: none"> 8 highest priority frames from queue 3 4 frames from queue 2 2 frames from queue 1 1 frame from queue 0 <p>Default: Strict Priority Queuing</p>
remap-priority	<p>Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to.</p> <p>Original Priority -----> New Priority</p> <p>Values: 0-7</p>
ingress-rate	<p>Restricts ingress frames on the fiber port.</p> <p>Default: None</p> <p>Data Options: 64 kbps to 90 Mbps</p>
egress-rate	<p>Restricts egress frames on the fiber port.</p> <p>Default: None</p> <p>Data Options: 64 kbps to 90 Mbps</p>
filter-unknown-multicast	<p>When enabled, multicast frames with unknown destination addresses are not allowed to egress this port.</p> <p>Default: Disabled</p>
filter-unknown-unicast	<p>When enabled, unicast frames with unknown destination addresses are not allowed to egress this port.</p> <p>Default: Disabled</p>
default-vlan-id	<p>Specify a default VLAN ID to insert when tagging frames.</p> <p>Default: 1</p> <p>Data Options: 0-4095</p>
default -priority	<p>Specify a default VLAN priority to insert when tagging frames.</p> <p>Default: 0</p> <p>Data Options: 0-7</p>
vlan-tagging-action	<p>Define the VLAN tagging action to take on a egress frame.</p> <ul style="list-style-type: none"> ● Normal -Take no action. ● Untag - Remove any existing tag. ● Tag <ul style="list-style-type: none"> Insert tag with configured VLAN ID and VLAN priority if original frame is untagged. Replace tag with configured VLAN ID and VLAN priority if original frame is tagged. ● Double tag - Append a tag with configured VLAN ID and VLAN priority. <p>Default: Normal</p>

Set slot... cm-1110

Description	Configure a cm-1110 media converter module.
User Level	Admin
Syntax	<pre> set slot <slot #> cm-1110 module [name <text>] [fiber-fault-alert enabled disabled] [link-mode standard smart-link-passthrough] [max-packet-size 1522 2048 10240] [map-priority-to-egress-queue <0-7> <0-3>] [unidirectional-ethernet disabled copper-to-fiber fiber-to-copper] set slot <slot #> cm-1110 copper [port enabled disabled] [name <text>] [crossover auto mdi mdi-x] [auto-negotiation enabled disabled] [pause disabled symmetrical asymmetrical-tx asymmetrical-rx] [10baset-distance normal extended] [downshift <0-8>] [8021p-priority enabled disabled priority enabled disabled] [priority-precedence 8021p ip-tos] congestion-policy [strict-queueing weighted-queueing] [remap- priority <0-7> <0-7> [ingress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps 200mbps 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps] [default-priority <0-7>] [default-vlan-id <0-4095>] [discard-tagged-frames enabled disabled] [discard-untagged-frames enabled disabled] [vlan-tagging-action none untag tag double-tag] [filter-unknown-multicast enabled disabled] [filter-unknown-unicastmulticast enabled disabled] set slot <slot #> cm-1110 fiber [port enabled disabled] [name <text>] [auto-negotiation enabled disabled] [8021p-priority enabled disabled] [ip-tos-priority enabled disabled] [priority-precedence 8021p ip-tos] congestion-policy [strict-queueing weighted-queueing] [remap- priority <0-7> <0-7> [ingress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps 200mbps 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps] [default-priority <0-7>] [default-vlan-id <0-4095>] [discard-tagged-frames enabled disabled] [discard-untagged-frames enabled disabled] [sgmii-interface enable disable] [vlan-tagging-action none untag tag double-tag] [filter-unknown-multicast enabled disabled] [filter-unknown-unicastmulticast enabled disabled] </pre>
module	This command defines parameters which apply to the whole media converter module.
name	The name to be associated with this module. 0-63 characters

fiber-fault-alert	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p>Note: This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
link-mode	<p>Standard: In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection.</p> <p>Smart Link Pass-Through: In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter.</p> <p>Default: Passthrough</p>
max-packet-size	<p>Select the maximum packet size.</p> <p>Options: 1522, 2048, 10240</p> <p>Default: 1522</p>
unidirectional ethernet	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p>Values:</p> <ul style="list-style-type: none"> ● Disabled ● Copper to Fiber ● Fiber to Copper <p>Default: Disabled</p>
map priority to egress queue	<p>This is the default egress priority mapping for both the copper and fiber ports.</p> <p>Priority 0 (lowest priority)..Queue 0 Priority 1.....Queue 0 Priority 2.....Queue 1 Priority 3.....Queue 1 Priority 4.....Queue 2 Priority 5.....Queue 2 Priority 6.....Queue 3 Priority 7 (highest priority)..Queue 3</p>
copper	<p>This command defines parameters which apply to the copper port of the media converter module.</p>
port	<p>Enable or disable this port.</p>
name	<p>The name to be associated with this port.</p>
crossover	<ul style="list-style-type: none"> ● Auto-Detect— automatically detects the Ethernet’s cable polarity ● MDI—the cable’s polarity is straight-through ● MDI-X—the cable’s polarity is crossovered <p>Default: Auto</p>

auto-negotiation	When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection.
pause	<p>pause</p> <p>When enabled, the Media Converter Module will advertise the following Pause capabilities:</p> <ul style="list-style-type: none"> ● Disabled ● Symmetrical ● Asymmetrical TX ● Asymmetrical RX <p>Note: Pause feature will only work if Auto Negotiation is set to OFF on the fiber port and Duplex is set to Full.</p>
10baset-distance	<p>Normal: the Media Converter copper link is in normal operating mode.</p> <p>Extended: the Media Converter will boost the signal strength on its copper link.</p>
downshift	<p>When enabled, the number of retries the Media Converter Module will attempt to establish a fiber connection at 1000 Mbps before attempting a lower speed.</p> <p>Default: Off</p>
8021p- priority	<p>When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue.</p> <p>Default: Enabled</p>
ip-tos-priority	<p>When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue.</p> <p>Default: Enabled</p>
priority- precedence	<p>When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence.</p> <p>Default: 802.1p</p>
congestion-policy	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues.</p> <p>Strict Priority Queuing - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p>Weighted Fair Queuing - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of (8, 4, 2, 1).</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <ul style="list-style-type: none"> 8 highest priority frames from queue 3 4 frames from queue 2 2 frames from queue 1 1 frame from queue 0
remap-priority	<p>Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to.</p> <p>Original Priority -----> New Priority</p> <p>Values: 0-7</p>

ingress-rate	Restricts ingress frames on the copper port. Default: None Data Options: 64 kbps to 900 mbps
egress-rate	Restricts egress frames on the copper port. Default: None Data Options: 64kbps to 900 mbps
discard-tagged-frames	When enabled, discards all VLAN tagged frames. Default: Off
discard-untagged-frames	When enabled, discards all VLAN untagged frames. Default: Off
sgmii-interface	Enable sgmii interface if your SFP supports this interface.
default-vlan-id	Specify a default VLAN ID to insert when tagging frames. Default: 1 Data Options: 0-4095
default-priority	Specify a default VLAN priority to insert when tagging frames. Default: 0 Data Options: 0-7
vlan-tagging-action	Define the VLAN tagging action to take on a egress frame. <ul style="list-style-type: none"> ● Normal -Take no action. ● Untag - Remove any existing tag. ● Tag <ul style="list-style-type: none"> Insert tag with configured VLAN ID and VLAN priority if original frame is untagged. Replace tag with configured VLAN ID and VLAN priority if original frame is tagged. ● Double tag - Append a tag with configured VLAN ID and VLAN priority. Default: Normal
fiber	This command defines parameters which apply to the fiber port of the media converter module.
port	Enable or disable this port.
name	The name to be associated with this port. 1-8 characters
auto-negotiation	Enabled: The Media Converter Module will negotiate Ethernet parameters on the fiber connection. This will ensure that the most optimal connection parameters will be in effect. Disabled: The Media Converter Module will negotiate the Ethernet parameter's with the copper link partner. The parameters used will be determined by the Duplex and Pause settings.
802.1p-priority	When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue. Default: Enabled
ip-tos-priority	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. Default: Enabled

priority- precedence	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. Default: 802.1p
congestion-policy	Select a method to be used when determining the order by which frames are sent from the four egress queues. Strict Priority Queuing - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues. Weighted Fair Queuing - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of (8, 4, 2, 1) . The ratio for 8 highest priority sent frames will be as follows: 8 highest priority frames from queue 3 4 frames from queue 2 2 frames from queue 1 1 frame from queue 0
remap-priority	Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to. Original Priority -----> New Priority Values: 0-7
ingress-rate	Restricts ingress frames on the fiber port. Default: None Data Options: 64 kbps to 900 mbps
egress-rate	Restricts egress frames on the fiber port. Default: None Data Options: 64 kbps to 900 mbps
filter-unknown- multicast	When enabled, multicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
filter-unknown- unicast	When enabled, unicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
default-vlan-id	Specify a default VLAN ID to insert when tagging frames. Default: 1 Data Options: 0-4095
default-priority	Specify a default VLAN priority to insert when tagging frames. Default: 0 Data Options: 0-7

vlan-tagging-actions

Define the VLAN tagging action to take on a egress frame.

- Normal - Take no action.
- Untag - Remove any existing tag.
- Tag
 - Insert tag with configured VLAN ID and VLAN priority if original frame is untagged.
 - Replace tag with configured VLAN ID and VLAN priority if original frame is tagged.
- Double tag - Append a tag with configured VLAN ID and VLAN priority.

Default: Normal

Set slot... cm-10g

Description
User Level
Syntax

Configure a cm-10g media converter module.
 Admin

For STS modules only

```
set slot <slot#> cm-10g [fiber-auto-negotiation enabled|disabled]
```

*For SFP ports

```
set slot <slot#> cm-10g module [fiber-fault-alert
disabled|enabled] [link-mode standard|smart-link-passthrough]
[name <name>]
```

```
set slot <slot#> cm-10g [port 1|2] [edc-mode
auto|linear|limiting|cx1] [frequency-control
enable|disable] [channel <1-65535>] [name <text>] [port
enabled|disabled] [tx-dither-control enable|disabled]
[wave-length-control enable|disable wavelength <0-65535>]
```

* Note: See manufacturers documentation for parameter settings.

*For XFP ports

```
set slot <slot#> cm-10g [port 1|2] [fec
enabled|disabled] [amplitude-adjustment <-128 -
127>] [phase-adjustment <-128 - 127>] [frequency-control
enable|disable] [channel <1-65535>] [name <text>] [port
enabled|disabled] [tx-dither-control enable|disabled]
[wave-length-control enable|disable] [wavelength <0-65535>]
```

* Note: See manufacturers documentation for parameter settings.

fiber-fault-alert

When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.

Note: This feature only takes effect if Fiber Negotiation has been turned off.

When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.

link-mode	<p>Smart Link Pass-Through: In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.</p> <p>Standard: In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.</p> <p>Default: Smart Link Pass-Through</p>
port	<p>Select the port to configure.</p> <p>Values: 1 or 2</p>
edc-mode	<p>Settings: Auto, linear, limiting, CX1</p> <p>Default: Auto</p> <p>* Note: See manufacturers documentation for parameter settings.</p>
frequency-control	<p>Settings:</p> <p>Channel number 1-65535</p> <p>* Note See manufacturers documentation for parameter settings</p>
name	<p>The name to be associated with this port.</p> <p>Values: 0-63 characters</p>
tx-dither-control	<p>Enable or Disable</p> <p>Default: Disable</p> <p>* Note: See manufacturers documentation for parameter settings.</p>
wavelength-control	<p>Enable or Disable</p> <p>Channel number: 0-65535</p> <p>* Note See manufacturers documentation for parameter settings</p>
name	<p>The name to be associated with this port.</p> <p>Values: 0-63 characters</p>
port	<p>Enable or disable this port.</p>
fec	<p>Enable or Disable</p> <p>Settings:</p> <p>Amplitude Adjustment: -128 to 127</p> <p>Phase Adjustment: -128 to 127</p> <p>Default: Disabled</p> <p>* Note: See manufacturers documentation for parameter settings.</p>
fiber-auto-negotiation	<p>When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection. This applies to 1000 SFP modules only.</p> <p>Default: Enabled</p>

Set slot... cm-10gt

Description	Configure a cm-10gt media converter module.
User Level	Admin
Syntax	<pre> *For SFP ports set slot <slot#> cm-10g module [fiber-fault-alert disabled enabled] [link-mode standard smart-link-passthrough] [name <name>] set slot <slot#> cm-10g [port 1 2] [edc-mode auto linear limiting cx1][*frequency-control enable <channel 1-65535> disable] [name <text>] [port enabled disabled] [*tx-dither-control enable mode enabled disabled] [*wave-length-control enabled <wavelength 0-65535> disable] * Note: See manufacturers documentation for parameter settings. *For XFP ports set slot <slot#> cm-10g [port 1 2] [fec enabled disabled] [amplitude-adjustment <-128 - 127>] [phase-adjustment <-128 - 127>] [frequency-control enable channel <1-65535> disable] [name <text>] [port enabled disabled] [*tx-dither-control enable mode enabled disabled] [*wave-length-control enabled <wavelength 0-65535> disable] * Note: See manufacturers documentation for parameter settings. *For copper Ethernet only set slot <slot#> cm-10gt port 2 duplex [half auto] energy-efficient-ethernet [name <text>] [enabled disabled] pause [disabled symmetrical asymmetrical-tx asymmetrical-rx] [port enabled disabled] </pre>
fiber-fault-alert	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p>Note: This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
link-mode	<p>Smart Link Pass-Through: In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.</p> <p>Standard: In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.</p> <p>Default: Smart Link Pass-Through</p>
port	<p>Select the port to configure.</p> <p>Values: 1 or 2</p>

edc-mode	<p>Settings: Auto, linear, limiting, CX1 Default: Auto * Note: See manufacturers documentation for parameter settings.</p>
frequency-control	<p>Enable or Disable Channel number: 1-65535 * Note: See manufacturers documentation for parameter settings</p>
name	<p>The name to be associated with this module. Values: 0-63 characters</p>
tx-dither-control	<p>Enable or Disable Default: Disable * Note: See manufacturers documentation for parameter settings.</p>
wavelength-control	<p>Channel number; 0-65535 * Note: See manufacturers documentation for parameter settings</p>
name	<p>The name to be associated with this port. Values: 0-8 characters</p>
port	<p>Enable or disable this port.</p>
fec	<p>Settings: Amplitude Adjustment: -128 to 127 Phase Adjustment: -128 to 127 Default: Disabled * Note: See manufacturers documentation for parameter settings.</p>
duplex	<p>The following selections are available: Duplex: Auto, Half Default: Auto This duplex configuration parameter will only be used for 1 gigabit SPF modules. For 10 gigabit modules, full duplex will always be advertised</p>
energy-efficient-ethernet	<p>Enabled: When enabled, the media converter module will auto negotiate EEE with the attached EEE compliant devices/servers. Disabled: The media converter module will not auto negotiate EEE with attached the EEE compliant devices/servers. Default: Enabled</p>
pause	<p>The Media Converter Module can advertise the following Pause capabilities:</p> <ul style="list-style-type: none"> ● Symmetrical ● Asymmetrical TX ● Asymmetrical RX <p>Note: 1 Gigabit modules must have auto negotiation turned off on the fiber side in order for Pause to be advertised on the copper side. Default: Asymmetrical RX</p>

fiber-auto-negotiation When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection. This applies to 1000 SFP modules only.
Default: Enabled

Set slot... cm-4gpt

Description Configure a cm-4gpt media converter module.
User Level Admin
Syntax `set slot <slot#> cm-4gpt [port<1|2>[port enabled|disabled] [name <text>]`
`Set slot <slot#> cm-4gpt [module] [fiber-fault-alert disabled|enabled] [Link-mode standard|smart-link-passthrough] [name <text>] [rate-select low|high]`

port Select the port to configure.
Values: 1 or 2

port Enable or disable this port.

name The name to be associated with this port.
Values: 0-8 characters

fiber-fault-alert **Enabled:** If the media converter module detects a loss of fiber signal on its fiber receiver, it will disable its fiber transmitter on the same SFP. This, in effect, notifies the fiber link partner that an error condition exists on the fiber connection.
Disabled: The module will take no action when a loss of signal is detected
Default: Disabled.

link-mode **Smart Link Pass-Through:** In this mode, the fiber link state on one fiber connection is directly reflected through the media converter module to the other fiber connection. Since this media converter is protocol independent, it monitors the Signal Detect indicator from the SFP and reflects this on the TX port of the other SFP by turning off the transmitter. When the signal (Link) get restored and Signal Detect becomes active, the affected transmitter will get re-enabled.
Standard Mode: In Standard Mode the media converter module will monitor the fiber link in the same manner. If the Signal Detect goes down the media converter module will out a 25MHz signal on the TX port of the other SFP.
Default: Smart Link Pass-Through

name The name to be associated with this module.
Values: 0-63 characters

rate-select High Speed: When a multi-rate SFP is inserted, it is enabled for the higher speed of operation.
Low Speed: When a multi-rate SFP is inserted, it is enabled for the slower speed of operation.
Default: High

Set slot... ex

Description	Configure a ex media converter module.
User Level	Admin
Syntax	<pre> set slot <slot #> ex module [interlink-fault-feedback enabled disabled] [link-mode standard smart-link-passthrough] [map-priority-to-egress-queue <0-7> <0-3>] [unidirectional-ethernet disabled ethernet-to-vdsl vdsl-to-ethernet] set slot <slot #> ex ethernet [10baset-distance normal extended] 8021p-priority enabled disabled] [auto-negotiation enabled] [advertise <10-full 10-half 100-full 100-half all> disabled] [congestion-pol icy strict-queueing weighted queueing] [crossover auto mdi mdi-x] [default-priority <0-7>] [default-vlan-id <0-4095>] [discard-tagged-frames enable disabled] [discard untagged-frames enabled disabled] [downshift <0-8>] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [filter -unknown-multicast enabled disabled] [filter-unknown-unicast enable disable] [ingress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [ip-tos -priority enabled disabled] [name <text>] [pause disabled symmetrical asymmetrical-tx asymmetrical-rx] [port enabled disabled] [priority-precendence] 8021p ip-tos] [remap-priority <0-7>] [vlan-tagging-action none untag tag double-tag] set slot <slot #> ex vdsl [8021p-priority enabled disabled] [congestion-policy strict-queueing weighted queueing] [default-priority <0-7>] [default-vlan-id <0-4095>] [discard-tagged-frames enable disabled] [discard untagged-frames enabled disabled] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768kb ps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 2 0mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [fast-mode disabled enabled] [filter-unknown-multicast enabled disabled] [filter-unknown-unicast enable disable] [ingress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768kb ps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 2 0mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [ip-tos-priority enabled disabled] low-bandwidth-alarm downstream upstream <0-90000>] [name <text>] [over-ride-profile downstream upstream [bitswapping <enable disabled>]] </pre>

	<pre>[max-datarate <128-101064>] [max-interleave-delay <0-16>] [min-datarate <128-101064>] [min-inp <1-18>] [signal-to-noise-ratio <30-240>] [port enabled disabled] [priority-precedence 8021p ip-tos] [profile-type [auto <rate high-speed long-range> <symmetry asymmetric symmetric>] manual <1-33>] [remap-priority <0-7> <0-7>] [role auto local remote] [vlan-tagging-action none untag tag double-tag]</pre>
module	This command defines parameters which apply to the whole media converter module.
interlink-fault-feedback	<p>In this mode, the Ethernet Link will reflect the VDSL status, if the VDSL link is down the Ethernet Link will be down. If the VDSL link is up the Ethernet Link will be up.</p> <p>When Interlink Fault Feedback is disabled, the status of the VDSL interface will not be passed to its Ethernet interface.</p> <p>Default: Disabled.</p>
link-mode	<p>Standard: In this mode, the Ethernet Extender module will not pass the state of the Ethernet interface across the Line connection to its peer. A loss on the Ethernet interface can occur without affecting the peer connection.</p> <p>Smart-Link-Passthrough: In this mode, the Ethernet Extender module will keep the Ethernet interface in a down state until the VDSL line comes up. The Ethernet link will only be brought up if the remote Ethernet Extender has an Ethernet link up.</p> <p>Default: standard</p>
Map Priority to Egress Queue	<p>This is the default egress priority mapping for both the copper and fiber ports.</p> <p>Priority 0 (lowest priority).Queue 0 Priority 1.....Queue 0 Priority 2.....Queue 1 Priority 3.....Queue 1 Priority 4.....Queue 2 Priority 5.....Queue 2 Priority 6.....Queue 3 Priority 7 (highest priority).Queue 3</p>
Unidirectional Ethernet	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p>Values:</p> <ul style="list-style-type: none"> ● Disabled ● Ethernet to VDSL ● VDSL to Ethernet <p>Default: Disabled</p>
ethernet	This command defines parameters which apply to the ethernet port of the media converter module.
10baset-distance	<p>These parameters apply to the Ethernet interface on this module.</p> <p>Normal: the Media Converter copper link is in normal operating mode.</p> <p>Extended: the Media Converter will boost the signal strength on its copper link.</p>

8021p- priority	<p>When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue.</p> <p>Default: Enabled</p>
auto-negotiation	<p>Enabled: Advertise on the copper link one of the following: 10-full, 10-half, 100-full, 100-half, or all.</p> <p>Disabled: Do not advertise on the copper link.</p>
congestion-policy	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues.</p> <p>Strict Priority Queuing - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p>Weighted Fair Queuing - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of (8, 4, 2, 1).</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <p>8 highest priority frames from queue 3 4 frames from queue 2 2 frames from queue 1 1 frame from queue 0</p>
crossover	<ul style="list-style-type: none"> ● Auto-Detect— automatically detects the Ethernet’s cable polarity ● MDI—the cable’s polarity is straight-through ● MDI-X—the cable’s polarity is crossovered <p>Default: Auto</p>
default-priority	<p>Specify a default VLAN priority to insert when tagging frames.</p> <p>Default: 0</p> <p>Data Options: 0-7</p>
default-vlan-id	<p>Specify a default VLAN ID to insert when tagging frames.</p> <p>Default: 1</p> <p>Data Options: 0-4095</p>
discard-tagged-frames	<p>When enabled, discards all VLAN tagged frames.</p> <p>Default: Off</p>
discard-untagged-frames	<p>When enabled, discards all VLAN untagged frames.</p> <p>Default: Off</p>
downshift	<p>When enabled, the number of retries the Media Converter Module will attempt to establish a fiber connection at 1000 Mbps before attempting a lower speed.</p> <p>Default: Off</p>
egress-rate-limit	<p>Restricts egress frames on the copper/vdsl port.</p> <p>Default: None</p> <p>Data Options: 64 kbps to 90 Mbps</p>
fast-mode	<p>Fast mode reduces frame latency when using shorter cable distances.</p> <p>Default: Disabled</p> <p>Note: Using InterLink override values for upstream and downstream SNR and/or INP values may disable Fast mode.</p>

filter-unknown-multicast	When enabled, multicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
filter-unknown-unicast	When enabled, unicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
ingress-rate limit	Restricts egress frames on the copper/vdsl port. Default: None Data Options: 64 kbps to 90 Mbps
ip-tos-priority	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. Default: Enabled
low-bandwidth-alarm	When the upstream or downstream link is established, the Ethernet Extender module will check the low bandwidth value. If the data rate is below the threshold value, an SNMP trap will be generated. Values: 0-90000 (0 means off)
name	The name to be associated with this port. Values: 0-8 characters
over-ride-profile	Allows you to override advance VDSL settings: Select upstream or downstream to configure the following: max-datarate: 128-101064 kbps max-interleave-delay: 0-16 ms min-datarate: 128-101064 min-inp: 1-18 signal-to-noise-ratio: 30-240 bitswapping: enabled/disabled Note: Advanced VDSL settings are valid only for Ethernet Extenders that have been configured with a role of Local
bitswapping	As line conditions change, bitswapping allows the modem to swap bits around different channels without retraining as each channel becomes more or less capable. If bitswapping is disabled, the modem will need to retrain in order to adapt to changing line conditions. Default: Enabled
max-datarate	The maximum data rate of the VDSL link Values: 128 - 101064 kbps
max-interleave-delay	Interleaving is a method of taking packets, chopping them up into smaller bits and then rearranging them so that once contiguous data is now spaced further apart into a noncontinuous stream. This provides better noise protection but increases latency. Enter the maximum acceptable gap in the data. Values: 128 - 101064 kbps
min-datarate	The minimum data rate of the VDSL link Values: 128 - 101064 kbps
signal-to-noise-ratio	The Ethernet Extender module will attempt to maintain the desired SNR value by adjusting line settings. A larger dB number will result in less line errors and a more stable connection, but may result in slower speeds. Values: 30-240 (3-24 dB)

port	Enable or disable this port.
priority- precedence	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. Default: 802.1p
profile-type	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. Default: 802.1p
auto	Select profile type "auto" to select either high speed or long range and symmetry parameter.
manual	Select profile type "manual" to select from a profile list. Type ? to see complete list. Values: 1-33
high-speed	In this mode, the VDSL connection will be optimized for maximum attainable speeds.
long-range	In this mode, the VDSL connection will be optimized for distance and the achievable distance will be up to 1 mile (3km).
role	If both Ethernet Extenders are configured for Auto mode, a proprietary method of detection is implemented for each attempt to synchronize the local and remote Ethernet Extenders modules. However, it is preferable to set one Ethernet Extender module to local and the other Ethernet Extender module to remote since this may results in slightly faster training times and direct control over their roles. Local (CO): This Ethernet Extender module is set to local mode of operation. Remote (CPE): This Ethernet Extender module is set to the Remote mode of operation.
vlan-tagging- actions	Define the VLAN tagging action to take on a egress frame. <ul style="list-style-type: none"> ● Normal -Take no action. ● Untag - Remove any existing tag. ● Tag <ul style="list-style-type: none"> Insert tag with configured VLAN ID and VLAN priority if original frame is untagged. Replace tag with configured VLAN ID and VLAN priority if original frame is tagged. ● Double tag - Append a tag with configured VLAN ID and VLAN priority. Default: Normal

set slot... cm-10gr

Description	Configure a cm-10gr media converter module.
User Level	Admin
Syntax	set slot <slot#> cm-10gr module [fiber-fault-alert disabled enabled] [link-mode standard smart-link-passthrough] [latency-mode rate-converting cut-through] [map-priority-to-egress-queue <0 1 2 3 4 5 6 7> <0 1 2 3 4 5 6 7>] [max-packet-size 1522 2048 10240] [name <text>] [unidirectional-ethernet disabled port2-to-port1 port1-to-port2]

```

set slot <slot#> cm-10gr [port 1|2] [8021p-priority
enabled|disabled] [congestion-policy
strict-queuing|weighted-queuing] [default-priority
0|1|2|3|4|5|6|7] [discard-tagged-frames disable|enable]
[discard untagged-frames enable|disable]
[egress-rate-limit 64kbps |128kbps |192kbps | 256kbps |
320kbps | 384kbps | 512kbps | 768kbps | 1mbps | 2mbps |
3mbps | 4mbps | 5mbps | 6mbps |7mbps | 8mbps | 9mbps |
10mbps | 20mbps | 30mbps |40mbps | 50mbps | 60mbps| 70mbps
| 80mbps | 90mbps| 100mbps |200mbps |300mbps| 400mbps |
500mbps | 600mbps | 700mbps | 800mbps | 900mbps]
[ingress-rate-limit 64kbps | 128kbps |192kbps | 256kbps |
320kbps | 384kbps | 512kbps | 768kbps | 1mbps | 2mbps |
3mbps | 4mbps | 5mbps | 6mbps |7mbps | 8mbps | 9mbps |
10mbps | 20mbps | 30mbps |4 0mbps | 50mbps | 60mbps|
70mbps | 80mbps | 90mbps| 100mbps | 200mbps | 300mbps|
400mbps | 500mbps | 600mbps | 700mbps | 800mbps | 900mbps]
[fiber-auto-negotiation enabled|disabled]
[filter-unknown-multicast enable|disable] [filter unknown
unicasts enable|disable] [ip-tos-priority
enabled|disabled] [name <text>]
[pause disable|symmetrical|asymmetrical-tx|asymmetrical-rx] [port
enabled|disabled] [priority-precedence 8021p|ip-tos] [remap
priority <0|1|2|3|4|5|6|7> <0|1|2|3|4|5|6|7>] [sgmii
enabled|disabled] [*tx-dither-control enable mode
enabled|disabled] [*wave-length-control enabled <wavelength
0-65535>|disable] [vlan-tagging-action
none|untag|tag|double-tag]

```

* Note: See manufacturers documentation for parameter settings

module	This command defines parameters which apply to the whole media converter module.
fiber-fault-alert	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p>Note: This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
link-mode	<p>Smart Link Pass-Through: In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.</p> <p>Standard: In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.</p> <p>Default: Smart Link Pass-Through</p>
latency	<p>Rate Converting: Both ports can operate at the same or different speeds.</p> <p>Cut Through: Both ports need to be the same speed and in full duplex mode. Energy Efficient Ethernet must be disabled.</p> <p>Note: Other configurable features may not be enabled in cut-through mode.</p> <p>Default: Rate Converting</p>

max-packet-size	<p>Select the maximum packet size.</p> <p>Options: 1522, 2048, 10240</p> <p>Default: 1522</p>
map priority to egress queue	<p>This is the default egress priority mapping for both fiber ports.</p> <p>Priority 0 (lowest priority).Queue 0 Priority 1.....Queue 0 Priority 2.....Queue 1 Priority 3.....Queue 1 Priority 4.....Queue 2 Priority 5.....Queue 2 Priority 6.....Queue 3 Priority 7 (highest priority).Queue 3</p>
unidirectional ethernet	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p>Values:</p> <ul style="list-style-type: none"> ● Disabled ● Port 2 to Port 1 ● Port 1 to Port 2 <p>Default: Disabled</p>
8021p-priority	<p>When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue.</p> <p>Default: Enabled</p>
congestion-policy	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues.</p> <p>Strict Priority Queuing - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p>Weighted Queuing - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of (8, 4, 2, 1).</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <p>8 highest priority frames from queue 3 4 frames from queue 2 2 frames from queue 1 1 frame from queue 0</p>
default-priority	<p>Specify a default VLAN priority to insert when tagging frames.</p> <p>Default: 0</p> <p>Data Options: 0-7</p>
default-vlan-id	<p>Specify a default VLAN ID to insert when tagging frames.</p> <p>Default: 1</p> <p>Data Options: 0-4095</p>
discard-tagged-frames	<p>When enabled, discards all VLAN tagged frames.</p> <p>Default: Off</p>

discard-untagged-frames	When enabled, discards all VLAN untagged frames. Default: Off
egress-rate-limit	Restricts egress frames on the fiber port. Default: None Data Options: 64 kbps to 900 Mbps
ingress-rate-limit	Restricts egress frames on the fiber port. Default: None Data Options: 64 kbps to 900 Mbps
filter-unknown-multicast	When enabled, multicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
filter-unknown-unicast	When enabled, unicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
ip-tos-priority	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. Default: Enabled
name	The name to be associated with this port. Values: 0-8 characters
pause	When enabled, the Media Converter Module will advertise the following Pause capabilities: <ul style="list-style-type: none"> ● Disabled ● Symmetrical ● Asymmetrical TX ● Asymmetrical RX Note: Pause feature will only work if Auto Negotiation is set to OFF on the fiber port and Duplex is set to Full.
port	Enable or disable this port.
priority-precedence	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. Default: 802.1p
remap-priority	Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to. Original Priority ----> New Priority Values: 0-7
sgmii	Enable sgmii interface if your SFP supports this interface.
tx-dither-control	Enable or Disable Default: Disable * Note: See manufacturers documentation for parameter settings.

- vlan-tagging-actions** Define the VLAN tagging action to take on an egress frame.
- Normal -Take no action.
 - Untag - Remove any existing tag.
 - Tag
 - Insert tag with configured VLAN ID and VLAN priority if original frame is untagged.
 - Replace tag with configured VLAN ID and VLAN priority if original frame is tagged.
 - Double tag - Append a tag with configured VLAN ID and VLAN priority.
- Default:** Normal
- wavelength-control** Enable or Disable
- Channel number:** 0-65535
- * **Note** See manufacturers documentation for parameter settings

set slot... cm-10grt

Description	Configure a cm-10grt media converter module.
User Level	Admin
Syntax	<pre>set slot <slot#> cm-10grt module [fiber-fault-alert disabled enabled] [link-mode standard smart-link-passthrough] [name <text>] [latency-mode rate-converting cut-through] [max-packet-size 1522 2048 10240] map-priority-to-egress-queue 0 1 2 3 4 5 6 7] [1 2 3 4 5 6 7] [unidirectional-ethernet disabled copper-to-fiber fiber-to-copper] *For SFP port set slot <slot#> cm-10grt [port 1 2] [8021p-priority enabled disabled] [congestion-policy strict-queuing weighted-queuing] [default-priority 0 1 2 3 4 5 6 7] [discard-tagged-frames disable enable] [discard untagged-frames enable disable] [egress-rate-limit 64kbps 128kbps 192 kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1 mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbp s 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps 200mbp s 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps] [ingress-rate-limit 64kbps 128kbps 192 kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1 mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps 200mbps 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps] [fiber-auto-negotiation enabled [disabled <speed 10 100> duplex<half full>] [filter-unknown-multicast enable disable] [filter unknown unicasts enable disable] [ip-tos-priority enabled disabled] [name <text>] [pause disable symmetrical asymmetrical-tx asymmetrical-rx] [port enabled disabled] [priority-precedence 8021p ip-tos] [remap priority <0 1 2 3 4 5 6 7> <0 1 2 3 4 5 6 7>] [sgmii enabled disabled] [*tx-dither-control enable mode enabled disabled] [*wave-length-control enabled <wavelength 0-65535> disable] [vlan-tagging-action none untag tag double-tag] For copper Ethernet set slot <slot#> cm-10grt module [fiber-fault-alert disabled enabled] [link-mode standard smart-link-passthrough] [name <text>] [latency-mode rate-converting cut-through] [max-packet-size 1522 2048 10240] map-priority-to-egress-queue 0 1 2 3 4 5 6 7] [1 2 3 4 5 6 7] unidirectional-ethernet disabled copper-to-fiber fiber-to-copper] set slot <slot#> cm-10grt port 2 [25gbaset-distance normal extended] [802.1p-priority enable disable] [congestion-policy strict-queuing weighted-queuing] [crossover auto mdi mdix] [default-priority 0 1 2 3 4 5 6 7] [default-vlan <0-4095> [discard-tagged-frames enable disable] [discard-untagged-frames enable disable] [downshift <0-8>] [egress-rate-limit 64kbps 128kbps 192 kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20m bps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps 200 mbps 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps] [energy-efficient-ethernet enable disable] [filter-unknown-multicast enabled disabled] filter-unknown-unicast enabled disabled] [ingress 64kbps 128kbps 192 kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20m bps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps 200 mbps 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps]</pre>

```
[energy-efficient-ethernet enable|disable]
[filter-unknown-multicast enabled|disabled]
filter-unknown-unicast enabled|disabled] [ingress
64kbps|128kbps|192|kbps|256kbps|320kbps|384kbps|512kbps|768kbps|
1mbps|2mbps|3mbps|4mbps|5mbps|6mbps|7mbps|8mbps|9mbps|10mbps|20m
bps|30mbps|40mbps|50mbps|60mbps|70mbps|80mbps|90mbps|100mbps|200
mbps|300mbps|400mbps|500mbps|600mbps|700mbps|800mbps|900mbps]
[ip-tos-priority enabled|disabled] [name <text>] [pause
disable|symmetrical|asymmetrical-tx|asymmetrical-rx] port
enabled|disabled] [priority-precedence 8021p|ip-tos] [remap
priority <0|1|2|3|4|5|6|7> <0|1|2|3|4|5|6|7>]
[vlan-tagging-action none|untag|tag|double-tag]
```

- module** This command defines parameters which apply to the whole media converter module.
- 25gbase-T distance** **Normal:** the Media Converter copper link is in normal operating mode.
Extended: the Media Converter will boost the signal strength on its copper link.
- fiber-fault-alert** When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.
Note: This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.
- link-mode** **Smart Link Pass-Through:** In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.
Standard: In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.
Default: Smart Link Pass-Through
- latency** **Rate Converting:** Both ports can operate at the same or different speeds.
Cut Through: Both ports need to be the same speed and in full duplex mode. Energy Efficient Ethernet must be disabled.
Note: Other configurable features may not be enable in cut-through mode.
Default: Rate Converting
- max-packet-size** **Select the maximum packet size.**
Options: 1522, 2048, 10240
Default: 1522

map priority to egress queue	<p>This is the default egress priority mapping for both fiber ports.</p> <p>Priority 0 (lowest priority).Queue 0 Priority 1.....Queue 0 Priority 2.....Queue 1 Priority 3.....Queue 1 Priority 4.....Queue 2 Priority 5.....Queue 2 Priority 6.....Queue 3 Priority 7 (highest priority).Queue 3</p>
unidirectional ethernet	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p>Values:</p> <ul style="list-style-type: none"> ● Disabled ● Copper to Fiber ● Fiber to Copper <p>Default: Disabled</p>
crossover	<ul style="list-style-type: none"> ● Auto-Detect— automatically detects the Ethernet’s cable polarity ● MDI —the cable’s polarity is straight-through ● MDI-X —the cable’s polarity is crossovered <p>Default: Auto</p>
downshift	<p>When enabled, the number of retries the Media Converter Module will attempt to establish a fiber connection at 1000 Mbps before attempting a lower speed.</p> <p>Default: Off</p>
8021p-priority	<p>When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue.</p> <p>Default: Enabled</p>
congestion-policy	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues.</p> <p>Strict Priority Queuing - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p>Weighted Queuing - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of (8, 4, 2, 1).</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <p>8 highest priority frames from queue 3 4 frames from queue 2 2 frames from queue 1 1 frame from queue 0</p>
default-priority	<p>Specify a default VLAN priority to insert when tagging frames.</p> <p>Data Options: 0-7 Default: 0</p>
default-vlan-id	<p>Specify a default VLAN ID to insert when tagging frames.</p> <p>Data Options: 0-4095 Default: 1</p>

discard-tagged-frames	When enabled, discards all VLAN tagged frames. Default: Off
discard-untagged-frames	When enabled, discards all VLAN untagged frames. Default: Off
egress-rate-limit	Restricts egress frames on the fiber port. Default: None Data Options: 64 kbps to 900 Mbps
ingress-rate-limit	Restricts egress frames on the fiber port. Default: None Data Options: 64 kbps to 900 Mbps
filter-unknown-multicast	When enabled, multicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
filter-unknown-unicast	When enabled, unicast frames with unknown destination addresses are not allowed to egress this port. Default: Disabled
ip-tos-priority	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. Default: Enabled
name	The name to be associated with this port. Values: 0-8 characters
priority-precedence	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. Default: 802.1p
remap-priority	Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to. Original Priority ----> New Priority Values: 0-7
sgmii	Enable sgmii interface if your SFP supports this interface.(sfp port 1 only)
vlan-tagging-actions	Define the VLAN tagging action to take on a egress frame. <ul style="list-style-type: none"> ● Normal -Take no action. ● Untag - Remove any existing tag. ● Tag <ul style="list-style-type: none"> Insert tag with configured VLAN ID and VLAN priority if original frame is untagged. Replace tag with configured VLAN ID and VLAN priority if original frame is tagged. ● Double tag - Append a tag with configured VLAN ID and VLAN priority. Default: Normal
port	Select the port to configure. Values: 1 or 2
name	The name to be associated with this module. Values: 0-63 characters

tx-dither-control	Enable/disable tx-dither-control Default: Disable * Note: See manufacturers documentation for parameter settings.
wavelength-control	Enable/disable wavelength control wavelength number: 0-65535 * Note See manufacturers documentation for parameter settings
name	The name to be associated with this port. Values: 0-8 characters
port	Enable or disable this port.
energy-efficient-ethernet	Enabled: When enabled, the media converter module will auto negotiate EEE with the attached EEE compliant devices/servers. Disabled: The media converter module will not auto negotiate EEE with attached the EEE compliant devices/servers. Default: Enabled
pause	The Media Converter Module can advertise the following Pause capabilities: <ul style="list-style-type: none"> ● Symmetrical ● Asymmetrical TX ● Asymmetrical RX Note: 1 Gigabit modules must have auto negotiation turned off on the fiber side in order for Pause to be advertised on the copper side. Default: Asymmetrical RX
auto-negotiation	Enabled: The Media Converter Module will negotiate Ethernet parameters on the copper connection. This will ensure that the most optimal connection parameters will be in effect. Disabled: The Media Converter Module will negotiate the Ethernet parameter's with the copper link partner. The parameters used will be determined by the Duplex and Pause settings. See duplex and speed for settings
duplex	When auto-negotiation is set to off select duplex for this copper port. Duplex: Full, Half
speed	When auto-negotiation is set to off select speed for this copper port. Specify the baud rate. Data Options: 10, 100
fiber-auto-negotiation	When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection. Fiber auto negotiation only for 1000mbps SFP's. Default: Enabled

Show slot * command

Description	Displays what module is inserted in each slot.
User Level	Admin, Operator

Syntax `show slot *`

Show slot # command

Description	Depending on the module inserted information about that specific slot will be displayed.
User Level	Admin, Operator
Syntax	<pre> show slot <slot #> fiber [config sfp statistics] [sfp thresholds] show slot <slot #> fiber [1 2] config show slot <slot #> copper [config statistics] show slot <slot #> port [1 2] [config xfp sfp] [xfp sfp thresholds] show slot <slot #> alerts show slot <slot #> details show slot <slot #> link-test show slot <slot #> module show slot <slot #> port show slot <slot #> power schedule show slot <slot #> switches </pre>

Show chassis alerts

Description	Displays the local alert log.
User Level	Admin, Operator
Syntax	<code>show chassis alerts</code>

Show chassis details

Description	Displays the chassis firmware and serial number info.
User Level	Admin, Operator
Syntax	<code>show chassis details</code>



User Commands

Commands for active sessions

Admin

Description	Changes a Operator-level user to the Admin user. When you press Enter after you type this command, you will be prompted for the Admin password.
User Level	Operator
Syntax	<code>admin</code>

Help

Description	Displays help on using the command line interface (CLI).
User Level	Operator, Admin
Syntax	<code>help</code>

Logout

Description	Logs the user out from the MCR-MGT Management Module.
User Level	Operator, Admin
Syntax	<code>logout</code>

Menu

Description	Switches from a command line based interface to Menu mode of operation.
User Level	Operator, Admin
Syntax	<code>menu</code>

Ping

Description	This command checks to see if a given host is reachable via an IP message. The specific message used is called a ping.
User Level	Operator, Admin
Syntax	<code>ping [destination] [<packet_size>] [<#_of_packets>]</code>
destination	This can be a "hostname" or an "IP address" The name (DNS resolvable host name) or IP address of the machine you are trying to ping.
packet-size	Enter the number of data bytes to be sent. The default is 100 bytes.
#of packets	Enter the number of the packets you want to send. The default is 10.

Screen

Description	Switches from a command line based interface to Menu mode of operation.
User Level	Operator, Admin
Syntax	screen

Set Termttype

Description	Sets the type of terminal being used on the console port.
User Level	Operator, Admin
Syntax	set termttype [type]
type	Specifies the type of terminal connected to the console port <ul style="list-style-type: none"> ● Dumb ● WYSE60 ● VT100 ● ANSI ● TVI925 ● IBM3151TE ● VT320 (specifically supporting VT320-7) ● HP700 (specifically supporting HP700/44)

Syslog Console

Description	Starts/stops or displays the status of the syslog console.
User Level	Admin, Operator
Syntax	syslog console [start stop]
	syslog console [status]
start	Start or stop console logging. When console logging is enabled, syslog messages will be echoed to the console. These messages are filtered based on the level set in the (remote) syslog options.
stop	
status	Displays the current console logging status (enabled or disabled).

Show Termttype

Description	Shows the terminal type for the current session.
User Level	Admin, Operator
Syntax	show termttype

Version

Description	Displays firmware version and build.
User Level	Operator, Admin
Syntax	version

Configuring Users

Add User

Description	Add a new user to the local user database.
User Level	Admin
Syntax	add user <username>

username The name of the user, without spaces. When you finish the command and press Enter, you will be prompted to enter and re-enter a password for the user.

Delete User

Description Deletes a user.
User Level Admin
Syntax `delete user <config_user>`
delete-user You can see a list of users that can be deleted by typing `delete user ?`. You can not delete the `admin` user.

Set User

Description Sets users settings.
User Level Admin
Syntax `set user username [level] [password]`
username The name of an existing user in the local user database.
level The access that a user is allowed:

- **Admin**—The admin level user has total access to the MCR-MGT Management Module. You can create more than one admin user account but we recommend that you only have one. They can monitor and configure the MCR-MGT Management Module.
- **Operator**—The Operator can fully operate the MCR-MGT Management Module but can not change any configurable parameters.

password The password the user will need to enter to login to the MCR-MGT Management Module. This case-sensitive field accepts a maximum of 16 characters.

Show User

Description Shows user configuration settings.
User Level Admin, Operator
Syntax `show user <configured_user>|. .`
configured user Show the settings for the specified user.
. Show the settings for the current user.



Network Commands

SNMP Commands

Add Community

Description	Adds an SNMP community (version 1 and version 2).
User Level	Admin
Syntax	add community <community_name> <config-host> <internet-address> [none readonly readwrite]
community-name	SNMP community name>
config- host	The host name or IP address of the SNMP community that will send requests to the MCR-MGT Management Module.
internet-address	
none readonly readwrite	The permission rights for this SNMP community.

Set SNMP

Description	Configures SNMP settings.
User Level	Admin
Syntax	set snmp [contact] [location][readonly user] [readwrite user] [engine-id-suffix]
contact	The name and contract information of the person who manages this SMNP node.
location	The physical location of the SNMP node.
readonly user	(SNMP version 3) Specified user can only view SNMP variables.
readwrite user	(SNMP version 3) User that can view and edit SNMP variables.
engine-id- suffix	This is the engine ID suffix which will be used with V3 traps. It is used to help identify the trap sender to the trap receiver. It is a unique identifier of the SNMP agent in the domain. By default the Engine ID is composed using the serial number of the Management Module which should make it unique. If you wish to assign a different engine ID to this node, use the "custom" keyword followed by the engine ID suffix string. If you want to revert to the default engine ID, use the "default" keyword. When changing the engine ID, the string entered in this field will be combined with other required elements to form the EngineID. It is up to the user to ensure that this will be a unique string.

Set SNMP V3-Security

Description	Configures SNMP settings for the Version 3 read-write, read-only and trap user(s).
User Level	Admin
Syntax	set snmp v3-security [usertype] [security-level] [auth-algorithm] [auth-password] [privacy-algorithm] [privacy-password]
usertype	Specify the security parameters for each of the "readonly" and "readwrite" user types. This parameter defines which of the two user types this applies to. Valid options are; <ul style="list-style-type: none"> readonly readwrite
security-level	Select the security level for the user. This must match the configuration set up in the SNMP manager. <p>Data Options:</p> <ul style="list-style-type: none"> ● None—No security is used. ● Auth—User authentication is used. ● Auth/Priv—User authentication and privacy (encryption) settings are used. <p>Default: None</p>
auth-algorithm	Specify the authentication algorithm that will be used for the user. <p>Data Options: MD5, SHA</p> <p>Default: MD5</p>
auth-password	If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.
privacy-algorithm	Specify the encryption algorithm to be used with this user. <p>Data Options: DES, AES</p> <p>Default: DES</p>
privacy-password	If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.

Set snmp-trap common

Description	Adds an SNMP host to which trap messages will be sent.
User Level	Admin
Syntax	set snmp-trap common [inform-retries] [inform-timeout] [level] [mode]
inform-retries	This is only used for "Inform" traps. Select the number of times the trap will be sent if no acknowledgement is received. The default is 3.
inform-timeout	This is only used for "Inform" traps. Select the number of seconds to wait for the acknowledgement of the trap. The default is 1 second.
level	Choose the event level that triggers an SNMP trap to be sent. <p>Data Options: system-level-fault, module-level-fault, persistent-error, one-time-error, significant-event, normal-operation</p>
mode	Enable or Disable the sending of traps.

Set snmp-trap entry

Description	Adds an SNMP host to which trap messages will be sent. Up to 4 trap host entries can be defined.
User Level	Admin

Syntax	set snmp-trap entry [entry#] [community] [internet-address] [mode] [type] [udp] [version]
entry #	Enter the entry number. Valid options are 1 - 4.
community	The name of the group that devices and management stations running SNMP belong to. This only applies to SNMP version 1 and version 2c.
internet-address	The IP address of the SNMP manager that will send requests to the MCR-MGT module. If the address is 0.0.0.0, any SNMP manager matching the Community name configured, can access the MCR-MGT module. If you specify a network address, for example 172.16.0.0, any SNMP manager residing on the 172.16.x.x subnet with a matching Community name can access the MCR-MGT module. Field Format: IPv4 or IPv6 address
mode	Enable or Disable this trap host entry.
type	This field is ignored for trap host version v1" Data Options: Trap - Management module will send traps via a TRAP_PDU or TRAP2-PDU not expecting any response from the specified host. Inform - Management module will send traps via an INFORM_PDU, expecting a response from the specified host. Default: Trap
udp	Enter the UDP port number that the SNMP trap host is listening on for UDP traps. Default: 162
version	Defines the SNMP version of the traps sent to the specified host. If v3 is selected then the SNMP trap v3 user will be used to authenticate the trap with the specified host. Valid options are v1, v2c or v3. Default: v1

Set snmp-trap v3

Description	Defines the parameters associated with the SNMP trap user for V3 traps.
User Level	Admin
Syntax	set snmp-trap v3 [username] [security-level] [auth-algorithm] [auth-password] [privacy-algorithm] [privacy-password]
username	This field identifies the system sending the traps to the host receiving the traps. Same user name is used for all v3 traps sent by this system.
security-level	Select the security level for the user. This must match the configuration set up in the SNMP manager. Data Options: <ul style="list-style-type: none"> ● None—No security is used. ● Auth—User authentication is used. ● Auth/Priv—User authentication and privacy (encryption) settings are used. Default: None
auth-algorithm	Specify the authentication algorithm that will be used for the user. Data Options: MD5, SHA Default: MD5
auth-password	If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.

privacy-algorithm Specify the encryption algorithm to be used with this user.

Data Options: DES, AES

Default: DES

privacy-password If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.

Delete Community

Description Deletes an SNMP community (version 1 and version 2).

User Level Admin

Syntax **delete community** <config_community_number>

config community number When you add an SNMP community, it gets assigned to a number. To delete the SNMP community, you need to specify the number of the community that you want to delete. To see which community is assigned to what number, type the **show snmp** command.

Show SNMP

Description Shows SNMP settings, including communities and traps.

User Level Admin, Operator

Syntax **show snmp**

Hosts Commands

Add Host

Description	Adds a host to the MCR-MGT Management Module host table.
User Level	Admin
Syntax	add host <hostname> <IP_address>
	add host <hostname> fqdn <text>
<ip-address>	This can be an IPv4 or IPv6 address
<hostname>	The name of the host. This is used only for the MCR-MGT Management Module configuration. Field Format: Up to 14 characters, no spaces.
fqdn	fqdn When you have DNS defined in the MCR-MGT Management Module, you can enter a DNS resolvable fully qualified domain name (note: FQDN's are excluded as accessible hosts when IP Filtering is enabled).

Delete Host

Description	Deletes a host from the MCR-MGT Management Module host table.
User Level	Admin
Syntax	delete host <config_host>
Option	<config_host> You can see a list of hosts that can be deleted by typing delete host? .

Set Host

Description	Modifies a host entry in the MCR-MGT Management Module host table.
User Level	Admin
Syntax	set host _default <config_host> <IP_address>
	set host <config_host> fqdn <text>
Options	<config_host> The name of the host. This is used only for the MCR-MGT Management Module configuration. Field Format: Up to 14 characters, no spaces.
<IP_address>	Assign a specific IP address and subnet to the MCR-MGT Management Module's Ethernet interface.
fqdn	When you have DNS defined in the MCR-MGT Management Module, you can enter a DNS resolvable fully qualified domain name (note: FQDN's are excluded as accessible hosts when IP Filtering is enabled).

Show Hosts

Description	Shows the MCR-MGT Management Module host table.
User Level	Operator, Admin
Syntax	show hosts

Add Authorized Host

Description	Adds a host to the MCR-MGT Management Module authorized host table.
User Level	Admin
Syntax	add authorized-host ip-address <IP_address> <description>
	add authorized-host mac-address <mac_address> <description>
<IP_address>	This can be an IPv4 or IPv6 address
<mac address>	The format is aa-bb-cc-dd-ee-ff.
<description>	This is a description which will help you identify this host.

Delete Authorized Host

Description	Deletes a host from the MCR-MGT Management Module authorized host table.
User Level	Admin
Syntax	delete authorized-host ip-address <IP_address>
	delete authorized-host mac-address <mac_address>
<IP_address>	IP address of a host in the table
<mac_address>	MAC address of a host in the table

Set Authorized Host

Description	Enables or Disables the use of the authorized host table. A security feature that when enabled, the Management Module will only accept data from or send data to hosts configured in the Authorized Host Table, Host Table, DNS Servers, SNMP communities, SNMP Traps, LDAP authentication Host IP server address, Email server Host IP address and Bootup files Host IP address. Host IP addresses must be configured with an IP address and not using FQDN.
User Level	Admin
Syntax	set authorized-hosts mode [enabled disabled]

Show Authorized Hosts

Description	Shows the status of the authorized host feature. Either Enabled or Disabled.
User Level	Admin, Operator
Syntax	show authorized-hosts

DNS Commands

Add DNS

Description	Adds a DNS entry.
User Level	Admin
Syntax	add dns <IP_address>
Option	<IP_address>

You can specify the IP addresses for up to four DNS (Domain Name Servers) hosts in your network.

Delete DNS

Description	Deletes a DNS entry.
User Level	Admin
Syntax	delete dns <config_dns_addr>
Option	<config_dns_addr>

You can view a list of configured DNS server IP addresses to choose from by typing **delete dns?**.

Show DNS

Description	Shows all DNS entries, even those supplied by DHCP/BOOTP when applicable.
User Level	Admin, Operator
Syntax	show dns

Gateway Commands

Add Gateway

Description	Adds a gateway. You can configure up to twenty gateways.
User Level	Admin
Syntax	<pre>add gateway <config_host> default add gateway <config_host> host <dest_IP_addr> add gateway <config_host> network <dest_IPv4_addr> <dest_IPv6_addr> [<subnet_bits_0-32> <prefix_bits_0-128>] add gateway specify-gateway ipv6tunnel <tunnel_name> default host <dest_IP_addr> network <dest_IPv4_addr> <dest_IPv6_addr> [<subnet_bits_0-32> <prefix_bits_0-128>]</pre>
Options	<p><config_host></p> <p>Select this option when a host is being used at the route gateway. Default: Enabled, None</p> <p>default host network</p> <p>ipv6tunnel <tunnel_name></p> <p><dest_IP_addr></p> <p><subnet_bits> <prefix_bits></p> <p>When the route is a Network route, you must specify the network's subnet mask.</p>

Delete Gateway

Description	Deletes a gateway.
User Level	Admin
Syntax	<pre>delete gateway <config_gateway_host></pre>
Option	<p><config_gateway_host></p> <p>You can view the configured gateways that can be deleted by typing <code>delete gateway?</code>.</p>

Set Gateway

Description	Modifies an existing gateway.
User Level	Admin
Syntax	<pre>set gateway <config_gateway_host> default set gateway <config_gateway_host> host <destination_ip> set gateway <config_gateway_host> network <dest_IPv4_addr> <dest_IPv6_address> <prefixbits_mask></pre>
Options	<p><config_gateway_host></p> <p>You can view the configured gateways that can be deleted by typing <code>delete gateway?</code>.</p> <p>default host network</p>

<destination_ip>
<prefixbits_mask>

Show Gateways

Description	Shows configured gateways.
User Level	Operator, Admin
Syntax	show gateways

Logging Commands

Set Syslog

Description	Configures the system syslog.
User Level	Admin
Syntax	set syslog [level emergency alert critical error warning notice info debug] [primary-host <config_host>] [secondary-host <config_host>]
level	Set level for syslog.
primary-host	Sets the primary host address for syslog messages to be sent to.
secondary-host	Sets the secondary host address for syslog messages to be sent to.

Show Syslog

Description	Shows the syslog settings.
User Level	Admin, Operator
Syntax	show syslog

Set event-log

Description	Configures the local system log.
User Level	Admin
Syntax	set event-log [level] [mode]
level	Choose the alert level that will trigger a notification to be sent to the local log. Data Options: System-level Fault Module Level Fault Persistent Error One-time error Significant Event Normal Operation. The level selected is the minimum trigger level with the "Normal Operation" being the least severe and "System-level Fault" being the most severe. The level selected will include alerts of that level and all more severe levels above it. Default: Normal Operation
mode	Enable or disable the local event log.

IPv6 Tunnels

Add IPv6tunnel

Description	Adds a new IPv6 tunnel.
User Level	Admin
Syntax	<code>add ipv6tunnel <tunnel_name></code>
tunnel name	Adds an IPv6 tunnel.

Set IPv6tunnel

Description	Configures the specified IPv6 tunnel.
User Level	Admin
Syntax	<code>set ipv6tunnel <config-tunnel-name> [mode manual teredo 6to4] [gateway <interface>] [remote-host <config_host>]</code>

config-tunnel-name
mode

Specify a IPv6 tunnel name.

The method or protocol that is used to create the IPv6 tunnel.

- **Manual**—When enabled, the MCR-MGT Management Module will manually create the IPv6 tunnel to the specified **Remote Host** through the specified **Interface**.
- **6to4**—When enabled, the MCR-MGT Management Module will broadcast to the multicast address 192.88.99.1 through the specified **Interface**. When the closest 6to4 router responds, it will create the IPv6 tunnel, encapsulating and decapsulating IPv6 traffic sent to and from the MCR-MGT Management Module.
- **Teredo**—When enabled, the Teredo protocol encapsulates the IPv6 packet as an IPv4 UDP message, allowing it to pass through most network address translator (NAT) boxes and create an IPv6 tunnel to the specified **Remote Host** (a Teredo server) through the specified **Interface**.

Default: Manual

gateway

The interface that the MCR-MGT Management Module is going to use to access the Remote Host.

Default: Ethernet 1

remote-host

The IPv4 host that can access the IPv6 network when the **Mode** is **Manual**.

The Teredo server when the **Mode** is **Teredo**.

Default: None

Show IPv6tunnel

Description	Shows the specified IPv6 tunnel settings.
User Level	Admin
Syntax	<code>show ipv6tunnel <config-tunnel-name></code>

Delete IPv6tunnel

Description	Controls the state of all IPsec tunnels.
User Level	Admin
Syntax	<code>delete ipv6tunnel <config-tunnel-name></code>
config tunnel name	<code><config-tunnel-name></code>

Deletes an IPv6 tunnel. If a tunnel is associated with a route, it cannot be deleted until the route is either changed or deleted.



Administration Commands

Administration Commands

Reboot

Description Reboots the MCR-MGT Management Module. You will be prompted to save configuration to FLASH, if there have been unsaved configuration changes.

User Level Admin, Operator

Syntax `reboot`

Reset Factory

Description Resets the MCR-MGT Management Module to the factory configuration.

User Level Admin

Syntax `reset factory`

Set Firmware auto-update

Description Automatically updates all managed Media Converter Modules with the bundled firmware.

User Level Admin

Syntax `set firmware auto-update [enabled | disabled]`

Show Firmware auto-update

Description Shows the status of the update Media Converter Modules firmware feature. Shows banded version firmware for each managed Media Converter Module.

User Level Admin

Syntax `show firmware auto-update`

Save

Description Saves the configuration to FLASH.

User Level Admin

Syntax `save`

Set Bootup

Description Specifies the TFTP host and pathname for files to be loaded after a MCR-MGT Management Module reboot.

User Level Admin

Syntax **set bootup firmware** [host <hostname>] [firmware file
 <path_filename>]

set bootup configuration [host <hostname>] [configuration file
 <path_filename>]

Options **firmware file**
 The name of the firmware file you wish to download.

configuration file
 The name of the configuration file you wish to download.

hostname
 This is the IP address or name of the host which holds the desired file. The name may
 either exist in the MCR-MGT Management Module's host table or must be resolvable
 using a DNS.

Show text-config

Description Shows the current configuration of the MCR-MGT Management Module in text format
 on the console.

User Level Admin, operator

Syntax **show text-confide**

Show Bootup

Description Shows the Firmware and Configuration files specified for MCR-MGT Management
 Module bootup.

User Level Admin, operator

Syntax **show bootup**

TFTP File Transfer Commands

Netload configuration and firmware

Note: *To download firmware, you will be asked to agree with Perle's Licensing Agreement and Privacy Policy. Type y to agree that you have read and understand these agreements. The firmware download will then continue.*

Description Transfers a file from a remote host to the MCR-MGT Management Module using the TFTP protocol.

User Level Admin

Syntax `netload text-config|firmware|configuration <hostname/IP_address> <filename>`

Options

text-config
Specify this option if you are uploading a text-based configuration file to the MCR-MGT Management Module from a TFTP server.

firmware
Specifies that you are going to download a new firmware file to the MCR-MGT Management Module.

configuration
Specifies that you are going to download a new configuration file to the MCR-MGT Management Module.

`<hostname/IP_address>`
The IP address or host name where the file you are downloading to the MCR-MGT Management Module resides. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

`<filename>`
The complete path and file name of the file you are downloading to the MCR-MGT Management Module (this path should be relative to the default path of your TFTP server, which may or may not allow drive letters).

Netsave configuration

Description Transfers a file from the MCR-MGT Management Module to a remote host using the TFTP protocol.

User Level Admin

Syntax `netsave configuration|diagnostic-file|serialt-buf|text-config <hostname/IP_address> <filename>`

Options

configuration
Specifies that you are going to upload a configuration file from the MCR-MGT Management Module to the specified host or IP address.

diagnostic-file
Specifies that you are going to upload a diagnostics file from the MCR-MGT Management Module to the specified host or IP address.

serialt-buf
Specifies that you are going to upload the contents of the serial trace buffer.

text-config
Specifies that you are going to upload the configuration in text format.

<hostname/IP_address>

The IP address or host name for where the file you are uploading from the MCR-MGT Management Module is going. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

<filename>

The complete path and file name for the file you are uploading from the MCR-MGT Management Module (this path should be relative to the default path of your TFTP server, which may or may not allow drive letters).

Keys and Certificates Commands

Netload keys

Description Loads certificates and keys into the MCR-MGT Management Module using TFTP.

User Level Admin

Syntax `netload ssl certificate|private-key <hostname/IP_address>
<filename>`

`netload ssh-server user <config_user> public-key ssh-2 rsa|dsa
<hostname/IP_address> <filename>`

Options `ssl certificate|private-key|ca-list`

If you are using the secure version of the WebManager (HTTPS), or LDAP authentication with TLS, then you need to download the SSL/TLS private key and CA list to make a secure connection.

public-key ssh-2

Specify ssh-2 when you are using SSH version 2.

rsa|dsa

When downloading keys to the MCR-MGT Management Module, specify the authentication method used by the key.

ssh-server user

The user that the SSH key is for.

`<hostname/IP_address>`

Enter the host or IP address that contains the certificate/key you are downloading to the MCR-MGT Management Module. If you are using a host name, If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

`<filename>`

Enter the complete path and file name of the certificate/key you are downloading to the MCR-MGT Management Module.

Netsave keys

Description Uploads certificates and keys from the MCR-MGT Management Module to a remote host using TFTP.

User Level Admin

Syntax `netsave ssh-server public-key ssh-2 rsa|dsa <hostname/IP_address>
<filename>`

Options `rsa|dsa`

When uploading SSH keys from the MCR-MGT Management Module, specify the SSH authentication method used by the SSH key.

`<hostname/IP_address>`

The IP address or host name for where the SSH key you are uploading from the MCR-MGT Management Module is going. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

<filename>

The complete path and file name for the file you are uploading from the MCR-MGT Management Module (this path should be relative to the default path of your TFTP server, which may or may not allow drive letters).

Netload Media Converter Modules

Note: *To download firmware, you will be asked to agree with Perle's Licensing Agreement and Privacy Policy. Type y to agree that you have read and understand these agreements. The firmware download will then continue.*

Description Loads firmware to Media Converter Modules.

User Level Admin

Syntax `netload media-converter firmware <slot #> <hostname/IP_address>
<filename>`

Options `slot`

The slot number of the Media Converter Module you wish to download the firmware to.

<hostname/IP_address>

Enter the host or IP address that contains the firmware file you are downloading to the Media Converter Module. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

<filename>

Enter the complete path and file name of the firmware file you are downloading to the Media Converter Module.

Netload Serialt-buf

Description Loads serial trace buffer data onto the management module.

User Level Admin

Syntax `netload serialt-buf <text>`

Options `<text>`

The name of the serial trace buffer file to be downloaded.

Netload sntp-keys

Description Loads sntp keys into the MCT-MGT management module.

User Level Admin

Syntax `netload sntp-keys <filename>`

Options `<filename>`

Enter the complete path and file name of the sntp key file you are downloading to the Media Converter Module.



Time Commands

Time Commands

Set Time

Description	Sets the MCR-MGT Management Module's system clock.
User Level	Admin
Syntax	<code>set time <hh:mm[:ss]></code>
Option	<code><hh:mm[:ss]></code>

Set Timezone

Description	Sets the MCR-MGT Management Module's time zone name and its offset from Greenwich Mean Time (UTC).
User Level	Admin
Syntax	<code>set timezone [name <string>] [offset + -<hh[:mm]>]</code>
name	The name of the time zone to be displayed during standard time. Field Format: Maximum 4 characters and minimum 3 characters (do not use angled brackets <>)
offset	The offset from UTC for your local time zone. Field Format: Hours <i>hh</i> (valid -12 to +14) and minutes <i>mm</i> (valid 0 to 59 minutes)

Show Time

Description	Shows the MCR-MGT Management Module's system clock.
User Level	Admin, Operator
Syntax	<code>show time</code>

Show Timezone

Description	Shows the time zone settings.
User Level	Admin, Operator
Syntax	<code>show timezone</code>

SNTP Commands

Add SNTP

Description	Adds an SNTP server.
User Level	Admin
Syntax	<code>add sntp [server-1 <config_host>] [server-2 <config_host>]</code>
server-1	The name of the primary SNTP server from the MCR-MGT Management Module host table. Valid with Unicast and Multicast modes, although in Multicast mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
server-2	The name of the secondary SNTP server from the MCR-MGT Management Module host table. Valid with Unicast and Multicast modes, although in Multicast mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.

Delete SNTP

Description	Deletes an SNTP server.
User Level	Admin
Syntax	<code>delete sntp server-1 server-2</code>
server-1	The name of the primary SNTP server from the MCR-MGT Management Module host table. Valid with Unicast and Multicast modes, although in Multicast mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
server-2	The name of the secondary SNTP server from the MCR-MGT Management Module host table. Valid with Unicast and Multicast modes, although in Multicast mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.

Set SNTP

Description	Configures an SNTP server.
User Level	Admin
Syntax	<code>set sntp mode none unicast anycast multicast {keyid-1 <number>} [keyid-2 <number>] [server-1 <config_host>] [server-2 <config_host>] [server-authentication enabled disabled] [version 1 2 3 4]</code>
mode	The SNTP mode. Data Options: <ul style="list-style-type: none"> ● None—SNTP is turned off. ● Unicast—Sends a request packet periodically to the Primary host. If communication with the Primary host fails, the request will be sent to the Secondary host. ● Multicast—Listen for any broadcasts from an SNTP server and then synchronizes its internal clock to the message. ● Anycast—Sends a request packet as a broadcast on the LAN to get a response from any SNTP server. The first response that is received is used to synchronize its internal clock and then operates in Unicast mode with that SNTP server. Default: None

server-1	The name of the primary SNTP server from the MCR-MGT Management Module host table. Valid with Unicast and Multicast modes, although in Multicast mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
server-2	The name of the secondary SNTP server from the MCR-MGT Management Module host table. Valid with Unicast and Multicast modes, although in Multicast mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
Key ID	Specify the key id associated with this host. This key must exist in the sntp (symmetric key) file that was downloaded to the MCR-MGT management card. Valid Key ID's: 1-65534 Note: the structure for the sntp (symmetric key) file can be found in the MCR-MGT User Guide - Appendix F (Symmetric Key File)
version	Version of SNTP. Range: 1-4 Default: 4

Show SNTP

Description	Shows the SNTP settings.
User Level	Admin, Operator
Syntax	show sntp

Show SNTP-Info

Description	Shows current SNTP information.
User Level	Admin, Operator
Syntax	show sntp-info

Time/Date Setting Commands

Set Date

Description	Sets the MCR-MGT Management Module's system clock.
User Level	Admin
Syntax	<code>set date <dd/mm/yyyy></code>

Set Summertime

Description	Sets the summertime clock.
User Level	Admin
Syntax	<code>set summertime [mode none fixed recurring] [name <text>] [offset <hh:mm>]</code>
mode	<p>You can configure the summer time to take effect:</p> <ul style="list-style-type: none"> • None—No summer time change. • Fixed—The summer time change goes into effect at the specified time every year. For example, April 15 at 1:00 pm. • Recurring—The summer time changes goes into effect every year at same relative time. For example, on the third week in April on a Tuesday at 1:00 pm. <p>Default: None</p>
<name>	<p>The name of the configured summer time zone; this will be displayed during the summer time setting. If this parameter is not set, then the summertime feature will not work.</p> <p>Field Format: Maximum 4 characters and minimum 3 characters (do not use angled brackets <>)</p>
offset	<p>The offset from UTC for your local time zone.</p> <p>Field Format: Hours <i>hh</i> (valid -12 to +14) and minutes <i>mm</i> (valid 0 to 59 minutes)</p>

Set Summertime Fixed

Description	Sets the summertime clock to start on the same date each year, for example, April 15 at 1:00 pm.
User Level	Admin
Syntax	<code>set summertime fixed [start-date january february ... <0-31>] [start-time <hh:mm>] [end-date january february ... <0-31>] [end-time <hh:mm>]</code>
start-date	The date to change to summer time and end standard time.
start-time <hh:mm>	The time to change to summertime. Valid values are 00:00 to 23:59.
end-date	The date to end summer time and start standard time.
end-time <hh:mm>	The time to change to standard time. Range: 00:00-23:59

Set Summertime Recurring

Description	Sets the summertime clock to start at the same relative time each year; for example, on the third week in April on a Tuesday at 1:00 pm.
--------------------	--

User Level	Admin
Syntax	<code>set summertime recurring [start-day monday tuesday ...] [start-month january february ...] [start-time <hh:mm>] [start-week 1 2 3 4 5 last] [end-day monday tuesday ...] [end-month january february ...] [end-time <hh:mm>] [end-week 1 2 3 4 5 last]</code>
start-day	The day to change to summer time from standard time.
start-month	The month to change to summer time from standard time.
start-time	The time to change to summer time from standard time; uses the format hh:mm for a 24-hour clock (00:00-23:59).
start-week	The week to change to summer time from standard time.
end-day	The day to end summer time and start standard time.
end-month	The month to end summer time and start standard time.
end-time	The time to end summer time and start standard time; uses the format hh:mm for a 24-hour clock (00:00-23:59).
end-week	The week to end summer time and start standard time.

Show Date

Description	Shows the date, according to the MCR-MGT Management Module system clock.
User Level	Admin, Operator
Syntax	<code>show date</code>

Show Summertime

Description	Shows the summertime settings.
User Level	Admin, Operator
Syntax	<code>show summertime</code>



Statistics Commands

Configuration Statistics

Show Interface

Description Shows IP statistics for Ethernet port.

User Level Admin, Operator

Syntax `show interface`

Run-Time Statistics

Delete Arp

Description Delete entries from the MCR-MGT Management Module's ARP cache. Takes effect immediately; not related to configuration.

User Level Admin

Syntax `delete arp`

Show Arp

Description Shows the current contents of the ARP cache.

User Level Admin, Operator

Syntax `show arp`

Uptime

Description Displays the elapsed time (in days, hours, minutes, and seconds) since the last reboot/power cycle.

User Level Admin, Operator

Syntax `uptime`